

MELSEC A Series

Programmable Logic Controllers

User's Manual

Digital-Analog Converter Modules A68DAV/A68DAI(S1)

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the PLC system safety precautions.


These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  **CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary.

Always forward it to the end user.



- Safety circuits should be installed external to the programmable controller to ensure that the system as a whole will continue to operate safely in the event of an external power supply malfunction or a programmable controller failure.
Erroneous outputs and operation could result in an accident.
 - 1) The following circuitry should be installed outside the programmable controller:
Interlock circuitry for the emergency stop circuit protective circuit, and for reciprocal operations such as forward/reverse, etc., and interlock circuitry for upper/lower positioning limits, etc., to prevent machine damage.
 - 2) When the programmable controller detects an abnormal condition, processing is stopped and all outputs are switched OFF. This happens in the following cases:
 - When the power supply module's over-current or over-voltage protection device is activated
 - When an error (watchdog timer error, etc.) is detected at the PLC CPU by the self-diagnosis function.Some errors, such as input/output control errors, cannot be detected by the PLC CPU, and there may be cases when all outputs are turned ON when such errors occur. In order to ensure that the machine operates safely in such cases, a failsafe circuit or mechanism should be provided outside the programmable controller. Refer to the CPU module user's manual for an example of such a failsafe circuit.
 - 3) Outputs may become stuck at ON or OFF due to an output module relay or transistor failure. An external circuit should therefore be provided to monitor output signals whose incorrect operation could cause serious accidents.
- Continuous overcurrent operation of the output module, due to operation over the rated capacity or load shorting, could result in smoke or fire. Always provide a safety circuit, such as an external fuse.
- A circuit should be installed which permits the external power supply to be switched ON only after the programmable controller power has been switched ON. Accidents caused by erroneous outputs and motion could result if the external power supply is switched ON first.
- When a data link communication error occurs, the status shown below will be established at the faulty station. In order to ensure that the system operates safely at such times, an interlock circuit should be provided in the sequence program (using the communication status information).
Erroneous outputs and operation could result in an accident.
 - 1) The data link data which existed prior to the error will be held.
 - 2) All outputs will be switched OFF at MELSECNET (II, /B, /10) remote I/O stations.
 - 3) At the MELSECNET/MINI-S3 remote I/O stations, all outputs will be switched OFF or output statuses will be held, depending on the E.C. mode setting.For details on procedures for checking faulty stations, and for operation statuses when such errors occur, refer to the appropriate data link manual.

[System Design Precautions]

 **CAUTION**

- Do not bundle control lines or communication wires together with main circuit or power lines, or lay them close to these lines.
As a guide, separate the lines by a distance of at least 100 mm, otherwise malfunctions may occur due to noise.
When file register R that are outside the range are read, e.g. by a MOV instruction, the file register data will become FFFF_H and use of this data will cause malfunctions. Take care not to use file registers that are outside the range when designing programs.
For details on instructions, refer to the Programming Manual.

[Cautions on Mounting]

 **CAUTION**

- Use the PC in an environment that conforms to the general specifications in the manual.
Using the PC in environments outside the ranges stated in the general specifications will cause electric shock, fire, malfunction, or damage to/deterioration of the product.
- Make sure that the module fixing projection on the base of the module is properly engaged in the module fixing hole in the base unit before mounting the module.
Failure to mount the module properly will result in malfunction or failure, or in the module falling.
- Extension cables should be securely connected to base unit and module connectors. Check for loose connection after installation.
A poor connection could result in contact problems and erroneous inputs/outputs.
- Plug the memory card firmly into the memory card mounting connector. Check for loose connection after installation. A poor connection could result in erroneous operation.
- Be sure to insert the memory securely into the memory socket.
After mounting, make sure that it does not lift up.
Poor contact could cause malfunctioning.

[Cautions on Wiring]



DANGER

- Switch off the external power supply before starting installation and wiring work.
Failure to do so could result in electrical shocks and equipment damage.
- After installation and wiring is completed, be sure to attach the terminal cover before switching the power ON and starting operation.
Failure to do so could result in electrical shocks.



CAUTION

- Be sure to ground the FG and LG terminals, carrying out at least class 3 grounding work with a ground exclusive to the PLC.
Otherwise there will be a danger of electric shock and malfunctions.
- Carry out wiring to the PC correctly, checking the rated voltage and terminal arrangement of the product. Using a power supply that does not conform to the rated voltage, or carrying out wiring incorrectly, will cause fire or failure.
- Outputs from multiple power supply modules should not be connected in parallel. Failure to do so could cause the power supply module to overheat, resulting in a fire or module failure.
- Tighten the terminal screws to the stipulated torque.
Loose screws will cause short circuits, fire, or malfunctions.
- Make sure that no foreign matter such as chips or wiring offcuts gets inside the module. It will cause fire, failure or malfunction.
- Connectors for external connections should be crimped, pressure welded, or soldered in the correct manner using the correct tools.
For details regarding crimping and pressure welding tools, refer to the input/output module user's manual.
A poor connection could cause shorts, fire, and erroneous operation.

[Cautions on Startup and Maintenance]

 **DANGER**

- Do not touch terminals while the power is ON.
This will cause malfunctions.
- Make sure that the battery is connected properly. Do not attempt to charge or disassemble the battery, do not heat the battery or place it in a flame, and do not short or solder the battery.
Incorrect handling of the battery can cause battery heat generation and ruptures which could result in fire or injury.
- Switch the power off before cleaning or re-tightening terminal screws.
Carrying out this work while the power is ON will cause failure or malfunction of the module.

 **CAUTION**

- In order to ensure safe operation, read the manual carefully to acquaint yourself with procedures for program changes, forced outputs, RUN, STOP, and PAUSE operations, etc., while operation is in progress. Incorrect operation could result in machine failure and injury.
- Do not disassemble or modify any module.
This will cause failure, malfunction, injuries, or fire.
- Switch the power OFF before mounting or removing the module.
Mounting or removing it with the power ON can cause failure or malfunction of the module.
- When replacing fuses, be sure to use the prescribed fuse.
A fuse of the wrong capacity could cause a fire.

[Cautions on Disposal]

 **CAUTION**

- Dispose of this product as industrial waste.

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Jul., 1991	IB (NA) 66285-A	First edition
Nov., 1997	IB (NA) 66285-B	<div data-bbox="646 421 778 454" style="border: 1px solid black; padding: 2px;">Correction</div> Section 2.2, Section 3.6, Section 4.6.2
Apr., 2001	IB (NA) 66285-C	<div data-bbox="646 521 833 555" style="border: 1px solid black; padding: 2px;">Adding models</div> A68DA-S1 <div data-bbox="646 629 746 663" style="border: 1px solid black; padding: 2px;">Addtion</div> WARRANTY <div data-bbox="646 730 778 763" style="border: 1px solid black; padding: 2px;">Correction</div> SAFETY PRECAVTIONS, Chapter 1, Section 2.2, 3.1, 3.2, 3.2.2, 3.4.1, 3.5.1, 3.6, 4.2, 4.5.2, 4.6.2, 5.2.1, 5.2.2, 5.2.3, Appendix 1

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end user.

CONTENTS

1. INTRODUCTION	1 - 1 ~ 1 - 1
1.1 Features	1 - 1
2. SYSTEM CONFIGURATION	2 - 1 ~ 2 - 4
2.1 Overall Configuration	2 - 1
2.1.1 Building block type CPU system	2 - 1
2.1.2 Compact type CPU system.....	2 - 2
2.2 Applicable A-Series Systems.....	2 - 3
2.3 Notes on Configuring the System.....	2 - 4
3. SPECIFICATIONS	3 - 1 ~ 3 - 21
3.1 General Specifications	3 - 1
3.2 Performance Specifications	3 - 2
3.2.1 I/O conversion characteristics of the A68DAV	3 - 4
3.2.2 I/O conversion characteristics of the A68DAI.....	3 - 7
3.3 Analog Output Control Functions.....	3 - 10
3.3.1 Analog output HOLD/CLEAR function at STOP of CPU.....	3 - 10
3.3.2 D-A conversion execute/non-execute setting function (D-A conversion output enable flag).....	3 - 10
3.3.3 Analog value external output enable/disable setting function (analog output enable/disable).....	3 - 10
3.3.4 Function combination.....	3 - 10
3.4 CPU I/O Signal	3 - 11
3.4.1 Overview of I/O signals	3 - 11
3.4.2 I/O signal functions	3 - 12
3.5 Buffer Memory.....	3 - 14
3.5.1 Buffer memory assignment.....	3 - 14
3.5.2 Analog output enable/disable channel area (Address 0 _H).....	3 - 15
3.5.3 CH.1 to CH.8 digital value area (Addresses 1 _H to 8 _H)	3 - 15
3.5.4 Resolution setting area of digital value (Address 9 _H)	3 - 16
3.5.5 CH.1 to CH.8 set value check code storage area (Addresses 10 _H to 17 _H)	3 - 17
3.6 Function Block Diagram	3 - 20
4. PRE-OPERATION SETTINGS AND PROCEDURES	4 - 1 ~ 4 - 10
4.1 Pre-operation Procedure.....	4 - 1
4.2 Handling Instructions	4 - 2
4.3 Nomenclature.....	4 - 3
4.4 HOLD/CLEAR Setting of Analog Output.....	4 - 5

4.5	Offset/Gain Setting.....	4 – 6
4.5.1	Notes on offset/gain setting	4 – 6
4.5.2	Offset/gain setting procedure.....	4 – 7
4.6	Wiring.....	4 – 8
4.6.1	Wiring instructions.....	4 – 8
4.6.2	Connection of A68DAV/DAI/DAI-S1 and external devices	4 – 8
4.6.3	Connection of connect the external power supply to the A68DAV/DAI.....	4 – 10
5.	PROGRAMMING	5 – 1 ~ 5 – 12
5.1	Programming Procedure.....	5 – 1
5.2	Sample Program	5 – 2
5.2.1	Digital value setting program.....	5 – 2
5.2.2	Program for the A68DAV/DAI loaded in remote I/O station	5 – 4
5.2.3	Program for the A68DAV/DAI loaded in remote I/O station (Use of the AnACPU dedicated instruction).....	5 – 9
6.	TROUBLESHOOTING.....	6 – 1 ~ 6 – 5
6.1	When the "RUN" LED Flashes or Goes OFF.....	6 – 1
6.2	When the Analog Value is 0V/0 mA.....	6 – 1
6.3	When Analog Values are Offset Values	6 – 2
6.4	Analog Values are Output though the CPU Module is set to STOP	6 – 3
6.5	When Digital and Analog Values do not Match.....	6 – 4
6.6	WDT Error Flag is Set.....	6 – 4
6.7	D-A Conversion READY Flag is Reset.....	6 – 4
6.8	Error Flag is Set	6 – 4
APPENDICES.....	APP – 1 ~ APP – 3	
APPENDIX 1	Comparison with Other D-A Converter Modules	APP – 1
APPENDIX 2	Dimensions	APP – 2
2.1	A68DAV	APP – 2
2.2	A68DAI.....	APP – 3

1. INTRODUCTION

This manual describes specifications, handling, programming and other information on the A68DAV digital-to-analog converter module (referred to as "A68DAV"), the A68DAI digital-to-analog converter module (referred to as "A68DAI") and the A68DAI-S1 digital-to-analog converter module (referred to as "A68DAI-S1") for use with a MELSEC-A series CPU module.

(1) A68DAV

Used to convert incoming digital values (16-bit signed binary data) which are set with the PC CPU to analog values (voltage outputs ranging from -10 V to 10 V).

(2) A68DAI/A68DAI-S1

Used to convert incoming digital values (16-bit signed binary data) which are set with the PLC CPU to analog values (voltage outputs ranging from 0 mA to 20 mA).

In the following section, A68DAI is used generically for A68DAI and A68DAI-S1.

A68DAV and A68DAI are referred to as "A68DAV/DAI" or "module" in this manual.

1.1 Features

(1) Allows digital-to-analog conversion for 8 channels.

The A68DAV/DAI can output analog values (voltage/current) to 8 external devices.

(2) Allows setting of resolution of digital values at three stages (all channels in batch).

Resolution of digital values can be set selecting from 1/4000, 1/8000 and 1/120000 by resolution setting.

(3) Allows analog output to be enabled/disabled on a channel basis.

Analog value output can be enabled or disabled for each channel by the sequence program.

The channel disabled for analog output provides an analog output value of 0 V or 0 mA.

(4) Allows setting of analog output to be held or cleared (all channels in batch) at STOP of CPU.

Holding of analog output when the CPU is at STOP can be set with the HOLD/CLEAR terminal.

(5) Allows offset/gain adjustment to be main without using offset/gain adjusting knobs.

The offset and gain values can be specified by the UP/DOWN switch for each channel.

2. SYSTEM CONFIGURATION

2.1 Overall Configuration

2.1.1 Building block type CPU system




Fig. 2.1 Building Block

REMARK

1) * An extension base cannot be connected to the A32B.

2.1.2 Compact type CPU system




Fig. 2.2 Compact Type CPU System Configuration

2.2 Applicable A-Series Systems

The A68DAV/DAI can be used only for the following A-series systems.

(1) The following CPU modules are suitable for A68DAV/DAI.

Applicable CPU modules		
A0J2CPU	A3UCPU	Q4ARCPU
A0J2HCPU	A4UCPU	A1SJCPU (S3)
A1NCPU	A73CPU	A1SJHCPU
A2NCPU	A81CPU	A1SCPU
A2NCPU-S1	A1CPU	A1SCPUC24-R2
A3NCPU	A2CPU	A1SHCPU
A3HCPU	A2CPU-S1	A2SCPU
A3MCPU	A3CPU	A2SHCPU
A2ACPU	Q2ACPU	A2USCPU (S1)
A2ACPU-S1	Q2ACPU-S1	A2USHCPU-S1
A3ACPU	Q3ACPU	Q2ASCPU (S1)
A2UCPU	Q4ACPU	Q2ASHCPU (S1)
A2UCPU-S1		

POINT

The A68DAV/DAI cannot be used in an A0J2P25/R25(remote I/O station).

(2) A68DAV/DAI may be loaded into any slot on the base unit with the following precautions:

- (a) When using the A68DAV/DAI with the A55B or A58B extension bases (i.e. those without power supplies), select the power supply for the main base unit in accordance with the relevant CPU module User's Manual.
- (b) When used with the A3CPU(P21/R21), the A68DAV/DAI cannot be loaded in the slot of the 7th extension stage in a system for which I/O allocation has been made or link X, Y defined in the parameters.
(These restrictions do not apply to A3NCPU, A3HCPU, A3MCPU, A73CPU, A3ACPU).

On a data link system, the A616DA can be mounted to any of the following: master station, local station or remote I/O.

Refer to the MELSECNET and MELSECNET/B data link system reference manual for examples of programs for remote I/O stations.

2.3 Notes on Configuring the System

- (1) When using the A68DAV/DAI, an external power supply is required to supply 24 VDC to the A68DAV/DAI.

When supplying a 24 VDC power, follow the power supply specifications mentioned in Section 3.2 Performance Specifications (external power supply). (refer to 4.6.3)

3. SPECIFICATIONS

This chapter describes the general specifications performance specifications, and I/O conversion characteristics of the A68DAV/DAI.

3.1 General Specifications

Table 3.1 shows the general specifications of the A68DAV/DAI.

Table 3.1 General Specifications

Item	Specifications					
Operating ambient temperature	0 to 55 °C					
Storage ambient temperature	-20 to 75 °C					
Operating ambient humidity	10 to 90 %RH, non-condensing					
Storage ambient humidity	10 to 90 %RH, non-condensing					
Vibration resistance	Conforming to *JIS B 3501, IEC 61132-2	—	Frequency	Acceleration	Amplitude	Sweep Count
		When there is Intermittent vibration	10 to 57 Hz	—	0.075 mm	10 times each in X, Y and Z axis (80 minutes)
			57 to 150 Hz	9.8 m/s ²	—	
		When there is continuous vibration	10 to 57 Hz	—	0.035 mm	
57 to 150 Hz	4.9 m/s ²		—			
Shock resistance	Conforming to JIS B3501, IEC 61131-2 (147 m/s ² , 3 times each in 3 directions)					
Operating environment	No corrosive gas present					
Operating height	2000 m (6582 ft) or less					
Installation area	On the control board					
Over-voltage category *1	II or less					
Pollution rate *2	2 or less					

*1: Indicates the distribution area where the device is assumed to be connected, from the public power distribution network to the local machine device. Category II is applied to the devices to which the power is supplied from a fixed equipment.
The surge resistance voltage of a rated 300 V device is 2500 V.

*2: This is an index which indicates the occurrence rate of the conductive object in the environment where the device is used.
Pollution rate II indicates that only non-conductive pollution may occur with a possibility of generating temporary conductivity due to accidental condensation.

3. SPECIFICATIONS

MELSEC-A

3.2 Performance Specifications

Table 3.2 shows the performance specifications of the A68DAV/DAI.

Table 3.2 Performance Specifications

Item	Specifications																																																									
	A68DAV		A68DAI																																																							
Digital input	(1) 16-bit signed binary data (2) Setting range:		(1) 16-bit signed binary data (2) Setting range:																																																							
	Resolution Setting	Setting Range	Resolution Setting	Setting Range																																																						
	1/4000	-4000 to 4000	1/4000	0 to 4000																																																						
	1/8000	-8000 to 8000	1/8000	0 to 8000																																																						
	1/12000	-12000 to 12000	1/12000	0 to 12000																																																						
Analog output	-10 to 0 to 10 VDC (External load resistance: 2 kΩ to 1 MΩ)		0 to 20 mADC (External load resistance: 0 to 600 Ω)																																																							
I/O characteristics	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="3">Digital Value Resolution</th> <th rowspan="2"></th> </tr> <tr> <th>1/4000</th> <th>1/8000</th> <th>1/12000</th> </tr> </thead> <tbody> <tr> <td rowspan="5">Digital input value</td> <td>4000</td> <td>8000</td> <td>12000</td> <td>+10 v</td> </tr> <tr> <td>2000</td> <td>4000</td> <td>6000</td> <td>+5 v</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0 v</td> </tr> <tr> <td>-2000</td> <td>-4000</td> <td>-6000</td> <td>-5 v</td> </tr> <tr> <td>-4000</td> <td>-8000</td> <td>12000</td> <td>-10 v</td> </tr> </tbody> </table>			Digital Value Resolution				1/4000	1/8000	1/12000	Digital input value	4000	8000	12000	+10 v	2000	4000	6000	+5 v	0	0	0	0 v	-2000	-4000	-6000	-5 v	-4000	-8000	12000	-10 v	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="3">Digital Value Resolution</th> <th rowspan="2"></th> </tr> <tr> <th>1/4000</th> <th>1/8000</th> <th>1/12000</th> </tr> </thead> <tbody> <tr> <td rowspan="4">Digital input value</td> <td>4000</td> <td>8000</td> <td>12000</td> <td>+20 mA</td> </tr> <tr> <td>2000</td> <td>4000</td> <td>6000</td> <td>+12 mA</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>+4 mA</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>			Digital Value Resolution				1/4000	1/8000	1/12000	Digital input value	4000	8000	12000	+20 mA	2000	4000	6000	+12 mA	0	0	0	+4 mA				
		Digital Value Resolution																																																								
1/4000		1/8000	1/12000																																																							
Digital input value	4000	8000	12000	+10 v																																																						
	2000	4000	6000	+5 v																																																						
	0	0	0	0 v																																																						
	-2000	-4000	-6000	-5 v																																																						
	-4000	-8000	12000	-10 v																																																						
	Digital Value Resolution																																																									
	1/4000	1/8000	1/12000																																																							
Digital input value	4000	8000	12000	+20 mA																																																						
	2000	4000	6000	+12 mA																																																						
	0	0	0	+4 mA																																																						
		* When offset setting is 0 V and gain setting is 10 V.																																																								
Maximum resolution of analog value *1	1/4000	2.5 mV		5.0 μA																																																						
	1/8000	1.25 mV		2.5 μA																																																						
	1/12000	0.83 mV		1.6 μA																																																						
Overall accuracy (accuracy to the maximum value) *2	±1.0 % (±100 mV)		±1.0 % (±200 μA)																																																							
Conversion time *3	Maximum 40 ms/8 channels (same for 1 channel) NOTE) Time from input of digital value till specified analog value (voltage/current) is output.																																																									
Absolute maximum output	Voltage: 0 to +12 V Current: 0 to +28 mA		NOTE) A voltage or a current that exceeds these ranges is not output by an output protection ladder.																																																							
Analog output points	8 channels/module																																																									
Insulation method	Photocoupler insulation between output terminals and PLC power (no insulation between channels)																																																									
Number of I/O points	32 points (I/O allocation: special function module)																																																									
Connection terminal	38 point terminal block																																																									
Applicable wire size	0.75 to 2 mm ² (Applicable tightening torque: 39N to 59N-cm)																																																									
Applicable solderless terminal	V1.25-3, V1.25-YS3A, V2-S3, V2-YS3A																																																									
Internal current consumption (5 VDC)	0.15 A		0.15 A																																																							
External power supply	Voltage	21.6 to 26.4 VDC																																																								
	Current consumption	0.2 A		0.4 A																																																						
Weight kg (lb)	0.6 Kg		0.65 Kg																																																							
External dimensions mm (in)	250 (9.24)(H) x 37.5 (1.48)(W) x 131 (5.16)(D)																																																									


***1 Maximum resolution of analog value**

The maximum resolution of analog value is the maximum variance in the analog output caused by a change in the digital value by "1".


***2 Overall accuracy**

Overall accuracy is the accuracy to the maximum value of analog output.

- 1) Overall accuracy of the A68DAV is the accuracy when the output voltage setting is 10 volts.



- 2) Overall accuracy of the A68DAI is the accuracy when the output voltage setting is 20 mA.



***3 Conversion speed**

The conversion speed is the length of time required from the reading of a digital value written to the buffer to the output of the specified analog value after D-A conversion. The conversion speed becomes the maximum when the maximum analog value output changes to the minimum analog value output, or vice versa. The maximum speed is 40 ms.

3.2.1 I/O conversion characteristics of the A68DAV

(1) I/O conversion characteristics

I/O characteristics are provided to convert a digital value specified from the CPU into an analog value and are indicated by an inclination connected between an offset value and a gain value.

(2) Offset/gain values

(a) The offset and gain values are defined as follows.

- 1) Offset value : Voltage output from the A68DAV when the digital value specified from the PLC CPU is "0".
- 2) Gain value : Voltage output from the A68DAV when digital value specified from the PLC CPU is "4000" (when digital value resolution setting is 1/4000).

(b) Offset/gain values are set before delivery as shown below.

- 1) Offset value : 0 V
- 2) Gain value : 10 V

(c) Offset/gain value can be changed for each channel in the test mode.

(3) I/O conversion characteristic example

The figure below shows an example of I/O conversion characteristics.




Fig. 3.1 I/O Conversion Characteristics

(4) Relation between offset/gain values and analog output

Resolution of the A68DAV can be changed as appropriate by offset/gain setting.

Resolution of analog value and analog output caused by digital input when offset/gain setting is changed are obtained as shown below.

$$(\text{Resolution of analog value}) = \frac{(\text{Gain value}) - (\text{Offset value})}{(\text{Resolution of digital value})}$$

$$(\text{Analog output}) = \frac{(\text{Gain value}) - (\text{Offset value})}{(\text{Resolution of digital value})} \times (\text{Digital input}) + (\text{Offset value})$$

$$= (\text{Resolution of analog value}) \times (\text{Digital input}) + (\text{Offset value})$$

The value of "resolution of digital value" (marked "*"1") varies depending on the setting at buffer address "9" (digital value resolution multiplication). For the calculation, use the following values.

Setting at Buffer Address "9"	Value Used for Resolution of Digital Value
1	4000
2	8000
3	12000

Section 3.6 gives buffer details.

POINT

Due to the nature of the D-A converter of the A68DAV, the variance value of analog output values in response to an increment/decrement of the digital input value by "1" might differ from the calculated value.

3. SPECIFICATIONS

(5) I/O conversion characteristics when offset/gain setting is changed

The figures below show the I/O conversion characteristics when offset/gain setting is changed.




Fig. 3.2 I/O Conversion Characteristics when Offset/Gain Setting is Changed

3.2.2 I/O conversion characteristics of the A68DAI

(1) I/O conversion characteristics

Since the I/O conversion characteristics are for converting the set digital values from the CPU to an analog value, they slanted by the joining of the offset value and gain value.

(2) Offset/gain values

(a) The offset and gain values are defined as follows.

- 1) Offset value : Voltage output from the A68DAI when the digital value specified from the PLC CPU is "0".
- 2) Gain value : Voltage output from the A68DAI when digital value specified from the PLC CPU is "4000" (when digital value resolution setting is 1/4000).

(b) Offset/gain values are set before delivery as shown below.

- 1) Offset value : 4 mA
- 2) Gain value : 20 mA

(c) Offset/gain value can be changed for each channel in the test mode.

(3) I/O conversion characteristic example

The figure below shows an example of I/O conversion characteristics.




Fig. 3.3 I/O Conversion Characteristics

(4) Relation between offset/gain values and analog output

Resolution of the A68DAI can be changed as appropriate by offset/gain setting.

Resolution of analog value and analog output caused by digital input when offset/gain setting is changed are obtained as shown below.

$$(\text{Resolution of analog value}) * 1 = \frac{(\text{Gain value}) - (\text{Offset value})}{(\text{Resolution of digital value})}$$

$$\begin{aligned} (\text{Analog output}) * 1 &= \frac{(\text{Gain value}) - (\text{Offset value})}{(\text{Resolution of digital value})} \times (\text{Digital input}) + (\text{Offset value}) \\ &= (\text{Resolution of analog value}) \times (\text{Digital input}) + (\text{Offset value}) \end{aligned}$$

The value of "resolution of digital value" (marked "*1") varies depending on the setting at buffer address "9" (digital value resolution multiplication). For the calculation, use the following values.

Setting at Buffer Address "9"	Value Used for Resolution of Digital Value
1	4000
2	8000
3	12000

Section 3.6 gives buffer details.

POINT

Due to the nature of the D-A converter of the A68DAV, the variance value of analog output values in response to an increment/decrement of the digital input value by "1" might differ from the calculated value.


3. SPECIFICATIONS

(5) I/O conversion characteristics when offset/gain setting is changed

The figures below show the I/O conversion characteristics when offset/gain setting is changed.

The right figure shows the I/O conversion characteristics when offset/gain setting is provided as follows.

No.	Offset Value	Gain Value
(1)	0 mA	20 mA
(2)	4 mA	20 mA
(3)	6 mA	16 mA



Example

(1) The analog output voltages are as follows at the digital input value settings of 2000 and 1000 for the characteristic graphs (1) to (3).

No.	Digital Input	Analog Output
(1)	2000	10 mA
	1000	5 mA
(2)	2000	12 mA
	1000	8 mA
(3)	2000	11 mA
	1000	8.5 mA

Fig. 3.4 I/O Conversion Characteristics when Offset/Gain Setting is Changed

3.3 Analog Output Control Functions

3.3.1 Analog output HOLD/CLEAR function at STOP of CPU

When the CPU is at STOP, or when the D-A conversion is stopped by the CPU module because of the occurrence of error, holding of analog output can be selected for all channels in batch with the HOLD/CLEAR terminal.

3.3.2 D-A conversion execute/non-execute setting function (D-A conversion output enable flag)

This function determines if each channel outputs a D-A conversion value or an offset value by setting a D-A conversion value output enable flag for each channel in the sequence program.

The D-A conversion time (conversion speed) is fixed disregarding of setting a D-A conversion value disable flag.

ON : D-A conversion value OFF: offset value

3.3.3 Analog value external output enable/disable setting function (analog output enable/disable)

This function determines if an analog value output to external devices is enabled or disabled by writing 0/1 to address 0 for each channel in the sequence program. Select one of the functions according to the state of the analog output to be set.

1 : 0 V/0 mA 0 : (D-A conversion value or offset value)

3.3.4 Function combination

When the CPU is at RUN or STOP, or when an error occurs in the CPU, analog values can be set as shown in Table 3.3 by combining any or all of the analog output control functions. Select the most appropriate combination.

Table 3.3 Analog Output State Setting Combinations

Setting Combination	HOLD/CLEAR Setting (Section 3.3.1)	CLEAR				HOLD	
	D-A Conversion Output Enable Flag (Section 3.3.2)	Enable (ON)		Disable (OFF)		Enable (ON)/Disable (OFF)	
	Output Status	Enable (0)	Disable (1)	Enable (0)	Disable (1)	Enable (0)	Disable (1)
Analog output at CPU STOP		Analog value after D-A conversion of digital value set with the PLC CPU is output.	0 V/0 mA	Offset value is output.	0 V/0 mA	Analog value after D-A conversion of digital value set with the PLC CPU is output.	0 V/0 mA
Analog output at CPU STOP		Offset value is output.	0 V/0 mA	Offset value is output.	0 V/0 mA	Analog value before STOP is held.	0 V/0 mA
Analog output at CPU error occurrence		0 V/0 mA	0 V/0 mA	0 V/0 mA	0 V/0 mA	0 V/0 mA	0 V/0 mA

3.4 CPU I/O Signal

3.4.1 Overview of I/O signals

The A68DAV/DAI uses 32 points of signals for input and output respectively.

Table 3.4 gives the allocation and description of I/O signals.

X devices refer to input signals from the A68DAV/DAI to the CPU.

Y devices refer to output signals from the CPU to the A68DAV/DAI.

The device numbers (input signals) shown in the table are used when the A68DAV/DAI is loaded into slot 0 of the main base unit.

Table 3.4 I/O Signals

Signal Direction: A68DAV/DAI → CPU		Signal Direction: CPU → A68DAV/DAI	
Device No.	Signal Description	Device No.	Signal Description
X0	WDT error flag (A68DAV/DAI detection)	Y0 through YC	Unusable (used for system only)
X1	D-A conversion READY	YD through YF	Interlock signal for RERP and RTOP instructions when the A68DAV/DAI is used as a remote I/O station.
X2	Error flag	X10 through Y17	D-A conversion value output enable flag
X3 through X1C	Unusable	Y18	Error reset flag
X1D through X1F	Interlock signal for RERP and RTOP instructions when the A68DAV/DAI is used as a remote I/O station.	Y19 through Y1F	Unusable (used for system only)

IMPORTANT

Because devices Y0 through YC and Y19 through Y1F are used in the system, they cannot be used in the sequence program.

If any of these devices are used (turned ON/OFF) in the sequence program, the functions of the A64DAV/DAI cannot be guaranteed.

If any of the devices Y0 through Y1F, has the same number as any of the devices X0 through X1F, that device cannot be used as an internal relay.

3.4.2 I/O signal functions

(1) WDT (watch dog timer) error flag (X0)

This flag is set when the self-diagnosis function of the A68DAV/DAI detects a WDT error. While the error flag is set, the D-A conversion of the A68DAV/DAI does not RUN (0 V/0 mA is output). If the error flag (X0) is set, a hardware malfunction may occur.

(2) D-A conversion READY signal (X1)

This signal is turned ON when the D-A conversion is ready after turning on or resetting the CPU in a mode other than the normal mode (test mode).

If the TEST terminals on the front of the module are connected to each other, this signal is turned OFF.

The D-A conversion READY signal (X1) can also be used as the buffer memory read/write interlock .

REMARK

In this manual, "D-A conversion READY" means the time when the analog output values have been output to external equipment by executing the D-A conversion with each channel.

(3) Error flag (X2)

This flag is set when an error (digital value setting error) other than the watch dog timer error occurs in the A68DAV/DAI.

This flag is reset when: (a) the error reset flag (Y18) is turned ON, or (b), "0" is written to the CH1 to CH8 set value check code storage areas (buffer 10 to 17).

(4) Interlock signals (X1D to X1F, YD to YF) for RFRP and RTOP instructions

(a) X1D and YD

One of these is set when the RFRP and RTOP instructions cannot be executed because of a module error.

When YD is turned ON, X1D is turned OFF.

(b) X1E and YE

While executing the RFRP instruction, YE is turned ON.

When the execution is completed, X1E flag is turned ON and YE remains ON.

Therefore, YE should be turned OFF by the sequence program.

(c) X1F and YF

While executing the RTOP instruction, YF is turned ON.

When the execution is completed, X1F is turned ON and YF remains ON.

Therefore, YF should be turned OFF by the sequence program.

POINT

Refer to the ACPU Programming Manual (Common Instructions) for the use of the interlock signals for the RFRP and RTOP instructions.

(5) D-A conversion output enable flag (Y10 to Y17)

If any of the D-A conversion enable flags for channels 1 to 8 are set, the D-A conversion value output of the corresponding channels is set to "enabled".

If a D-A conversion value output needs to be set to "disable", reset the corresponding D-A conversion enable flag.

Y10 : D-A conversion value output enable flag for channel 1


Y11 : D-A conversion value output enable flag for channel 2

⋮

Y17 : D-A conversion value output enable flag for channel 8

(6) Error reset signal (Y18)

Turning ON the error reset signal (Y18) resets the error flag (X2), and clears the check code stored in the setting value check code storage area (addresses 10 to 17) of the buffer memory. It is replaced by "0".



POINT

The I/O allocation numbers of the A68DAV/DAI mentioned in this manual are those when the A68DAV/DAI is loaded in slot No.0 of the main base unit.

3.5 Buffer Memory

The A68DAV/DAI has a buffer memory (not battery backed) for data communication with the CPU.

The buffer memory assignment and data maps are indicated below.

3.5.1 Buffer memory assignment

Address 2 (Decimal)		Default Value	Relevant Section
0	Analog output enable/ disable channel	0000 _H (all channels enabled)	Section 3.6.2
1	CH.1 digital value	0	Section 3.6.3
2	CH.2 digital value		
3	CH.3 digital value		
4	CH.4 digital value		
5	CH.5 digital value		
6	CH.6 digital value		
7	CH.7 digital value		
8	CH.8 digital value		
9	Resolution of digital value	1(1/4000)	Section 3.6.4
10	CH.1 set value check code	0	Section 3.6.5
11	CH.2 set value check code		
12	CH.3 set value check code		
13	CH.4 set value check code		
14	CH.5 set value check code		
15	CH.6 set value check code		
16	CH.7 set value check code		
17	CH.8 set value check code		

Fig. 3.5 Buffer Memory Assignment

POINT
 Addresses 10 to 17 of the buffer memory are the read-only area.
 When write is executed with a sequence program, an error will occur.

3.5.2 Analog output enable/disable channel area (Address 0_H)

- (1) Defines output enable/disable for the converted analog value per channel.
- (2) All channels are enabled for output when:
 - (a) Power is switched on; or
 - (b) CPU is reset.
- (3) Output disable/enable is defined by 1/0.
 - (a) Disable..... 1
 - (b) Enable 0
- (4) The analog output enable/disable channel area data map is shown below:




Fig. 3.6 Analog Output Enable/Disable Channel Area Data Map

3.5.3 CH.1 to CH.8 digital value area (Addresses 1_H to 8_H)

- (1) Write digital values to this area from the CPU for D-A conversion.
- (2) Digital values of all channels are set to 0 if:
 - (a) D-A conversion ready (X1) is ON after power on; or
 - (b) D-A conversion ready (X1) is switched ON after the CPU is reset.
- (3) Any digital value specified should be a 16-bit signed binary within the setting range of digital value resolution. Any digital value outside this range is changed to a value indicated below before D-A conversion, and the corresponding check code is written to the set value check code area (addresses 10 to 17).

Table 3.5 The Setting Range of Digital Value

Module	Digital Value Resolution	Setting Range	Digital Value for D-A Conversion when Values Outside the Special Ranges are Set.
A68DAV	1/4000	-4096 to 4095 (-4000 to 4000 : for guaranteed operation)	4096 or above : 4095 -4097 or below : -4096
	1/8000	-8192 to 8191 (-8000 to 8000 :for guaranteed operation)	8192 or above : 8191 -8193 or below : -8192
	1/12000	-12288 to 12287 (-12000 to 12000 : for guaranteed operation)	12288 or above : 12287 -12289 or below : -12288
A68DAI	1/4000	0 to 4095 (0 to 4000 : for guaranteed operation)	4096 or above : 4095 -1 or below : 0
	1/8000	0 to 8191 (0 to 8000 : for guaranteed operation)	8192 or above : 8191 -1 or below : 0
	1/12000	0 to 12287 (0 to 12000 : for guaranteed operation)	12288 or above : 12287 -1 or below : 0

3.5.4 Resolution setting area of digital value (Address 9_n)

- (1) The resolution set in the resolution setting area of digital value which corresponds to the range of analog output voltage is common to all channels.
- (2) The resolution value of digital value is "1" (1/4000) in the following cases.
 - (a) At power on.
 - (b) At reset of the PLC CPU.
- (3) The setting value should be 1, 2 or 3.

Table 3.6 Resolution Setting Range

Setting Value	Resolution of Digital Value
1	1/4000
2	1/8000
3	1/12000

POINT

(1) If the set value is other than 1, 2, or 3, the resolution value is not changed and is set to the last set value before set or to a default value.

(2) Set the resolution multiplication value only once before the D-A conversion value output enable flag is turned ON.
If the set value is changed while the D-A conversion enable flag is set, i.e. a machine is being controlled, the analog output will change causing machine control problems.

3.5.5 CH.1 to CH.8 set value check code storage area (Addresses 10_H to 17_H)

- (1) Used to check whether the set digital values are within or out of the setting range of digital value resolution.
- (2) The corresponding check code in Table 3.7 is stored if a digital value out of the setting range of digital value resolution is set.

Table 3.7 Check Code List

Check Code	Description
000F _H	A digital value over the setting range of digital value resolution was set.
00F0 _H	A digital value below the setting range of digital value resolution was set.
00FF _H	Digital values over and below the setting range of digital value resolution were set.

- (3) Any check code stored once is not reset even though the corresponding set value is corrected to a valid value (within the setting range of digital value resolution).

The check code should be reset by switching the error reset signal(Y18) ON.

POINT

The error flag(X2) is set ON to indicate that a check code has been stored to the set value check code area.

3.6 Function Block Diagram




Fig. 3.7 A68DAV Function Block Diagram




Fig. 3.8 A68DAI Function Block Diagram




Fig. 3.9 A68DAI-S1 Function Block Diagram

4. PRE-OPERATION SETTINGS AND PROCEDURES

4.1 Pre-operation Procedure




Fig. 4.1 Pre-operation Procedure


4.2 Handling Instructions

- (1) Protect the A68DAV/DAI and its terminal block from impact loads.
- (2) Do not remove the printed circuit boards from the housing. There are no user-serviceable parts on the boards.
- (3) Ensure that no conductive debris can enter the module. If it does, make sure that it is removed. Guard particularly against wire offcuts.
- (4) Tighten the screws as specified below:

Screw	Tightening Torque Range N·cm
I/O terminal screw (M3 screw)	39 to 59
I/O terminal block installation screw (M4 screw)	78 to 118

- (5) To load the module onto the base, press the module against the base so that the catch on the top of the unit is securely locked. To unload the module, push the catch, and after the catch is disengaged from the base, pull the module toward you.


4.3 Nomenclature



No.	Description	Application
1	"RUN" LED	<p>Indicates the operating status of the A68DAV/DAI.</p> <p>(Normal mode)</p> <p>On • Indicates that the A68DAV/DAI is operating without fault.</p> <p>Off • 5 VDC is not supplied to the A68DAV/DAI.</p> <p>• A68DAV/DAI is in WDT error.</p> <p>• A68DAV/DAI hardware fault has occurred.</p> <p>• PLC CPU has detected an error and stopped operation.</p> <p>Flash • A write data error has occurred.</p> <p>(Test mode)</p> <p>Flash { 0.5 s interval • OFFSET/GAIN select switch is in "OFFSET" or "GAIN" position.</p> <p>0.1 s interval • The high or low limit of the allowed range has been exceeded during offset/gain value setting using the UP/DOWN switch.</p> <p>• Offset value setting is greater than gain value setting using the UP/DOWN switch.</p> <p>Off • OFFSET/GAIN select switch is in "SET" position.</p>

4. PRE-OPERATION SETTINGS AND PROCEDURES

MELSEC-A

No.	Description	Application																				
2	Channel select switch CH. 	Used to specify the channel (CH.1 to CH.8) for offset/gain adjustment. Channels should be switched when the OFFSET/GAIN select switch is in "SET" position. Only valid in test mode. (Positions "0" and "9" are ineffective.)																				
3	OFFSET/GAIN select switch	Used to select any of the following modes: <ul style="list-style-type: none"> • OFFSET position : Offset value calibration mode. • GAIN position : Gain value calibration mode. • SET position : Offset/gain value storage mode. (The offset/gain value is stored to the A68DAV/DAI internal memory when the switch is moved from "OFFSET"/"GAIN" to "SET".) 																				
4	UP/DOWN switch	Used to define the offset/gain value for the specified channel. Increases or decreases the offset or gain value at the following rate: <ul style="list-style-type: none"> • UP/DOWN position for less than 1.5 seconds : Increase or decrease spell of 0.54 mV, 1.15 μA at one time. • UP/DOWN position for 1.5 seconds or more : Increase or decrease of 0.54 mV, 1.15 μA per 0.02 s. 																				
5	TEST mode terminals (terminal Nos. 1 and 3)	Used to select normal or test mode. <ul style="list-style-type: none"> • Disconnected : Normal mode (to output analog values to external devices) • Connected : Test mode (to set offset/gain values) 																				
6	Analog output HOLD/CLEAR setting terminals (terminal Nos. 2 and 4)	Used to hold or clear analog output at the time of CPU stop. (See Section 4.4.) <ul style="list-style-type: none"> • Disconnected : CLEAR • Connected : HOLD 																				
7	Analog output terminals (CH.1 to CH.8)	Used to output an analog value after D-A conversion. <table border="1" data-bbox="497 1108 1444 1303"> <thead> <tr> <th>Channel</th> <th>Terminal No.</th> <th>Channel</th> <th>Terminal No.</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>5, 6</td> <td>5</td> <td>21, 22</td> </tr> <tr> <td>2</td> <td>9, 10</td> <td>6</td> <td>25, 26</td> </tr> <tr> <td>3</td> <td>13, 14</td> <td>7</td> <td>29, 30</td> </tr> <tr> <td>4</td> <td>17, 18</td> <td>8</td> <td>33, 34</td> </tr> </tbody> </table>	Channel	Terminal No.	Channel	Terminal No.	1	5, 6	5	21, 22	2	9, 10	6	25, 26	3	13, 14	7	29, 30	4	17, 18	8	33, 34
Channel	Terminal No.	Channel	Terminal No.																			
1	5, 6	5	21, 22																			
2	9, 10	6	25, 26																			
3	13, 14	7	29, 30																			
4	17, 18	8	33, 34																			
8	Power terminals (terminal Nos. 36 and 38)	Input terminals for analog value output power supply (24 VDC).																				

4.4 HOLD/CLEAR Setting of Analog Output

This section explains how to define a HOLD/CLEAR setting of analog output when the CPU is in the STOP mode.

- (1) Use the HOLD/CLEAR terminal (on the front of the A68DAV/DAI module) to define the HOLD/CLEAR setting of analog output.

Table 4.1 describes the settings and their states.

Table 4.1 HOLD/CLEAR Setting

Analog Output Setting	State of HLD/CLR Terminal (Between Terminal Nos. 2 and 4)
HOLD	Connected
CLEAR	Not connected

The original(factory-set) analog output state is CLEAR(disconnected).

- (2) The analog output state by HOLD/CLEAR setting varies with settings of the D-A conversion value output enable flag (see Section 3.4.2) and the analog output enable/disable state (see Section 3.5.2).

Table 3.3 shows the analog output states for settings of the D-A conversion value output enable flag and the analog output enable/disable state. It also shows the analog output state when the CPU is in the RUN mode.

4.5 Offset/Gain Setting

- (1) The offset and gain values are factory-set to output the voltages indicated in Table 4.2.

Table 4.2 Factory-set Offset/Gain Values

	A68DAV	A68DAI
Gain value	10 V	20 mA
Offset value (V)	0 V	4 mA

- (2) The offset and gain values may be changed and fine-adjusted by offset/gain setting in test mode.

4.5.1 Notes on offset/gain setting

- (1) Do not select test mode during execution of D-A conversion. Selecting test mode stops D-A conversion of all channels and affects control of external devices. Returning from test mode to normal resumes D-A conversion with new offset/gain values.

- (2) Offset/gain setting is allowed within the following ranges:

(a) A68DAV : -10 V to 0 V to + 10 V

(b) A68DAI : -0 mA to 20 mA

If any value set is outside the above range, overall accuracy may not be within the range of performance specifications (see Section 3.2).

- (3) The defined value is stored when the OFFSET/GAIN select switch is set to the "SET" position.

The offset and gain value remain unchanged if test mode is terminated with the OFFSET/GAIN select switch in the "OFFSET" or "GAIN" position.

- (4) Before switching from one channel to another in test mode, the OFFSET/GAIN select switch should be set to the "SET" position.

If the channel remains unchanged and the set value is stored to the new channel when the switch is set to "OFFSET" or "GAIN".

- (5) The "RUN" LED flickers fast at intervals of 0.1 seconds to indicates that the offset/gain specified has exceeded the allowed range.

When the "RUN" LED is flickering fast, the offset/gain value remains unchanged if the OFFSET/GAIN select switch is set to "SET".

4.5.2 Offset/gain setting procedure




Fig.4.2 Offset/Gain Setting Procedure

4.6 Wiring

4.6.1 Wiring instructions

Protect external wiring against noise with the following precautions:

- (1) Separate AC and DC wiring.
- (2) Separate main circuit and/or high voltage wiring from control and signal wiring.
- (3) Where applicable, ground the shielding of all wires to a common ground point.

4.6.2 Connection of A68DAV/DAI/DAI-S1 and external devices

(1) Connection Example of A68DAV and External Devices




Fig. 4.3 Connection Example of A68DAV and External Devices

(2) Connection Example of A68DAI/A68DAI-S1 and External Devices




Fig. 4.4 Connection Example of A68DAI /A68DAI-S1 and External Devices

IMPORTANT


(1) When using the A68DAI, never route a common jumper on the side with the external device.
 If wiring is not routed independently for each channel to the module as shown above, proper amperage output will not be attained.
 When using the A68DAI-S1, a common jumper on the side with the external device can be routed.

(2) If a A68DAI-S1 inductor component load is continued, normal output may not be attained.

4.6.3 Connection of 24 VDC to the A68DAV/DAI

The following describes the method of supplying +24 VDC to the A68DAV/DAI.

- (1) To connect the external power supply, twisted-wire pair cable should be used to avoid electromagnetic inductive noise.
- (2) When the external power supply is used, it is recommended to use noise filters with the A68DAV/DAI.



POINT

- (1) The cables between the noise filters and A68DAV/DAI must not be bundled with any other cable.
- (2) The cables between the noise filters and A68DAV/DAI must be as short as possible.

5. PROGRAMMING

5.1 Programming Procedure

Program data transfer between the CPU and A68DAV/DAI as indicated in Fig. 5.1.




Fig.5.1 Programming Procedure

5.2 Sample Program

This section explains the programming used with the A68DAV/DAI.

IMPORTANT
<p>A FROM/TO instruction cannot be executed in the test mode. Use the D-A conversion ready signal as an interlock for any program that contains a FROM/TO instruction.</p> <p>If a FROM/TO instruction is executed in the test mode, the set offset and/or gain values might be lost, or a CPU error occurs.</p>

5.2.1 Digital value setting program

The following describes a program used to write a value (0 to 8000) to the digital value setting area (addresses 1 to 4 of the buffer memory) for channels 1 to 4 of the A68DAV/DAI. The value is set with a BCD digital switch.

Programming conditions

(1) System configuration


Power supply module	A 3 N C P U	A X 42 (64 points)	A Y 42 (64 points)	A 68 D A (V/I)		
		X00 to X3F	Y40 to Y7F	X/Y80 to X/Y9F	} I/O number	

(2) Initial settings

- (a) Digital value resolution "2" (1/8000)
- (b) Analog output disable channel CH.5, 6, 7, 8

(3) Device for user

- (a) Digital value write command input signal
 - 1) Channel No.1 X1
 - 2) Channel No.2 X2
 - 3) Channel No.3 X3
 - 4) Channel No.4 X4
- (b) Setting of digital value (4 digits in the BCD code) X30 to X3F
- (c) Digital value clear command X5
- (d) Digital value storage register D0



POINT

During each of the processes of the special function module, access from the PLC CPU will have priority. Accordingly, if frequent access to the buffer memory of the special function module made from the PLC CPU, it will not only extend the scan time of the PLC CPU, delays in each of the processes of the special function module will occur. Only use the FROM/TO and other such commands to access the buffer memory from the PLC CPU when necessary.

5.2.2 Program for the A68DAV/DAI loaded in remote I/O station

The following program is used to write a value (0 to 8000) defined by the BCD digital switch to channels 1 to 4 (addresses 1 to 4 of buffer memory) of the A68DAV/DAI in a remote I/O station.

Cautions on programming

(1) Data transfer method

The CPU has direct and refresh I/O control modes. Data transfer between the CPU and remote I/O station is made in batch refresh mode after execution of the END (FEND) instruction.

(2) Response delay

A time difference (response delay) occurs because control data transferred between the master station CPU and remote I/O station A68DAV/DAI is controlled through the link module. Control timing must therefore be noted.

(3) Instructions used

The following instructions are used for data transfer between the master station CPU and remote I/O station A68DAV/DAI.

(a) Data write (master station to A68DAV/DAI) : RTOP instruction

(b) Data read (A68DAV/DAI to master station) : RFRP instruction

(4) Device for data transfer

Link registers (W) are used for data transfer between the master station CPU and remote I/O station A68DAV/DAI. Write either of both of the following programs to the master station as appropriate:

(a) Data write : Program which transfers data (to be transferred to the remote I/O station A68DAV/DAI) to the specified link registers before execution of the RTOP instruction.

(b) Data read : Program which transfers data from the link registers to the other device after execution of the RFRP instruction.

(5) Disable simultaneous execution of RTOP and RFRP instructions

The RTOP and RFRP instructions cannot be executed at the same time to one A68DAV/DAI. To enable simultaneous execution, data link I/O signals must be written in the program as interlock conditions.

(When two A68DAV/DAI are loaded in the remote I/O station, the RTOP instruction may be executed to one A68DAV/DAI and the RFRP instruction to the other at the same time.)

(6) Control signals to the A68DAV/DAI

Because of the relation between the master station scan time and link scan time, the PLS Y[] signal output to the remote I/O station may not be provided to the A68DAV/DAI.

The pulse output which executes the RST instruction after the SET instruction cannot be used because data is transferred between the master station and remote I/O station in batch refresh mode after execution of the END (FEND) instruction.


(7) Detection of remote I/O station error or parameter communication

(a) Provide interlock using the following devices so that the RTOP/RFRP instruction is not executed when the remote I/O station is faulty or during initial communication with the remote I/O station.

1) Remote I/O station error detection : D9228 to D9231

2) Initial communication detection : D9224 to D9227

The remote I/O station error and initial communication detection timings are as shown below:



(b) The error detection program must be written before the initial communication detection program.

If these programs are written in reverse order, neither error nor initial communication may be detected depending on the link refresh timing.

(8) A68DAV/DAI error detection

(a) X1D is switched ON to indicate that the A68DAV/DAI is faulty and the RFRP/RTOP instruction cannot be executed. In this case, check the A68DAV/DAI for A68DAV/DAI fault, module loading error, etc.

(b) Switch ON YD to switch OFF X1D


YD must only be switched ON/OFF as described below by using the SET/RST instruction:

1) Switched ON when X1D is switched ON.

2) Switched OFF only once when X1D is switched OFF.

Programming condition

(1) System configuration



(2) Initial settings

- (a) Digital value resolution "2" (1/8000)
- (b) Analog output disable channel CH.5, 6, 7, 8

(3) Device for user

- (a) Initial setting command input signal X0
- (b) Digital value write command input signal
 - 1) Channel No.1 X1
 - 2) Channel No.2 X2
 - 3) Channel No.3 X3
 - 4) Channel No.4 X4
- (c) Setting of digital value (4 digits in the BCD code) X30 to X3F
- (d) Digital value clear command X5
- (e) Start/completion signal of each processing M0 to M16
- (f) Data storage register at an error detection D0, D1
- (g) Initial setting data register
 - 1) Resolution value register W101
 - 2) Analog output enable/disable channel setting data register W102
- (h) Digital value register
 - 1) Channel No.1 W111
 - 2) Channel No.2 W112
 - 3) Channel No.3 W113
 - 4) Channel No.4 W114

3) Channel No.3.....W113

4) Channel No.4.....W114


Programming Procedure


Detection of a remote I/O station error

Setting initial setting data

Writing a resolution multiplication value

1






5.2.3 Program for the A68DAV/DAI loaded in remote I/O station (Use of the AnACPU dedicated instruction)

The following program is used to write a value (0 to 8000) defined by the BCD digital switch to channels 1 to 4 (addresses 1 to 4 of buffer memory) of the A68DAV/DAI in a remote I/O station when AnACPU dedicated instructions are used.

Programming condition

(1) System configuration




(2) Initial settings


- (a) Digital value resolution "2" (1/8000)
- (b) Analog output disable channel CH.5, 6, 7, 8

(3) Device for user

- (a) Initial setting command input signal X0
- (b) Digital value write command input signal
 - 1) Channel No.1 X1
 - 2) Channel No.2 X2
 - 3) Channel No.3 X3
 - 4) Channel No.4 X4
- (c) Setting of digital value (4-digit in the BCD code) X30 to X3F
- (d) Digital value clear command X5
- (e) Start/completion signal of each program M0 to M9

- (f) Initial setting data storage link register
 - 1) Resolution value register..... W101
 - 2) Analog output enable/disable
channel setting data register W102
- (g) Digital value read data register D0
- (h) Digital value storage link register
 - 1) Channel No.1..... W111
 - 2) Channel No.2..... W112
 - 3) Channel No.3..... W113
 - 4) Channel No.4..... W114





6. TROUBLESHOOTING

Problem conditions and troubleshooting diagnoses for the A68DAV/DAI are given below. For information on the CPU module, see the corresponding CPU User's Manual.

6.1 When the RUN LED Flashes or Goes OFF

(1) When the RUN LED goes OFF:

Items to Check	Corrective Actions
Are the TEST terminals shorted? (Test mode)	Cancel the test mode by opening the TEST terminals.
Has an error occurred in the CPU module?	Refer to the appropriate User's Manual for error information, and correct the error
Is the power supply module (5 VDC) installed to the base unit not getting enough current?	Recalculate the total amperage for the CPU, I/O module, and special function module installed to the base unit, and replace the power supply module based on that calculation.
Is the A68DAV/DAI WDT error flag set?	Reset the CPU module.

(2) When the RUN LED flashes:

Items to Check	Corrective Actions
Has a digital value outside the set range been written?	Clear the set value check code storage area using the error reset flag.
Are the TEST terminals closed (test mode) with the offset/gain switch placed in either "OFFSET" or "GAIN"?	After setting the offset or gain value, open the TEST terminals.
Does the LED flash at 0.1 s intervals when in the test mode?	Make offset/gain setting within an allowable range.

6.2 When the Analog Value is 0 V/0 mA

(1) When the values of all channels are 0 V/0 mA:

Items to Check	Corrective Actions
Is the RUN LED of the A68DAV/DAI turned OFF?	Follow procedures in Section 6.1.
Is the WDT error flag set?	Follow procedures in Section 6.7.
Is the D-A conversion ready flag set?	Follow procedures in Section 6.8.
Is the channel set as the analog output enabled/disabled channel?	Set the channel to be used as the analog output enabled/disabled channel.
Is a digital value written to the digital value setting area (addresses 1 to 8) in the buffer?	Write the digital value to the channel used for D-A conversion (see Sections 3.5.3 and 5.2.).

(2) When the value of a given channel is 0 V/0 mA:

Items to Check	Corrective Actions
Is the analog output enable/disable channel with its "0 V/0 mA" analog value set to disable?	Confirm the data set in the analog output enable/disable channel setting area of the buffer memory. (Refer to Section 3.5.2.)
Is the digital value of the channel with its "0 V/0 mA" analog value written in the digital value setting area of the buffer memory?	Write the digital value. (Refer to Section 3.5.3.)
Is the external wiring done correctly?	Make sure the external wiring is correct.

6.3 When Analog Values are Offset Values

(1) When the analog values of all channels are offset values:

Items to Check	Corrective Actions
Are the TEST terminals shorted? (Test mode)	Cancel the test mode by opening the TEST terminals.
Is the RUN key switch of the CPU module set to a position other than "RUN"?	Set the switch to the RUN position
Is the D-A conversion output enable flag of each channel OFF?	Turn ON the D-A conversion output enable flag of the channel to be used.
Is the digital value setting area (addresses 1 to 8) of the buffer memory?	Write the digital values of the channel to be converted from digital to analog. (Refer to Sections 3.5.3 and 5.2)

(2) When the analog value of a given channel is an offset value:

Items to Check	Corrective Actions
Is the D-A conversion output enable flag OFF for the channel when the analog value is an offset value?	Turn ON the D-A conversion output enable flag.
Is the digital value of the channel whose analog value is an offset value written to the digital value setting area of the buffer memory?	Write the digital value. (Refer to Section 3.5.3.)

6. TROUBLESHOOTING

MELSEC-A

6.4 Analog Values are Output though the CPU Module is set to STOP

(1) When the analog output does not change after setting to STOP:

Items to Check	Corrective Actions
Are the HOLD/CLEAR setting terminals shorted(held)?	Open the HOLD/CLEAR setting terminals.

(2) When the analog output changes after setting to STOP:

Items to Check	Corrective Actions
Is the analog output set to offset value?	After checking the offset value setting, set the offset value again if 0 V/0 mA output is required.

6. TROUBLESHOOTING

MELSEC-A

6.5 When Digital and Analog Values do not Match

(1) When both digital values and analog values change:

Items to Check	Corrective Actions
Does the digital value match the analog value?	Correct the offset/gain values.
Are the A68DAV/A68DAI and external devices properly wired?	Make sure the wiring between the A68DAV/A68DAI and the external devices is correct.
Is the 24 VDC external power supply getting enough current?	Recalculate the total amperage for the module installed to the base unit, and replace the power supply module based on that calculation.

(2) When the digital value changes and the analog value is fixed:

Items to Check	Corrective Actions
Is 24 VDC power being supplied?	Check the external power supply.
Is the RUN key switch of the CPU module set to a position other than "RUN"?	Set the switch to the RUN position.

6.6 WDT Error Flag is Set

Item to Check	Corrective Actions
Is the WDT setting time shorter than the sequence program scan time?	Change the WDT setting time to conform to the sequence program scan time.
Is the sequence program correct?	Check if the sequence program contains an infinite loop.

6.7 D-A Conversion READY Flag is Reset

Items to Check	Corrective Actions
Are the TEST terminals closed (test mode)?	Cancel test mode by opening the TEST terminals.
Is there an error in the CPU module?	See the corresponding User's Manual for respective CPU module for error information. Correct the error.
Is there an I/O number error?	Confirm and correct the I/O number.

6.8 Error Flag is Set

Item to Check	Corrective Action
Is a value that is not "0" set in the setting value check code storage area (addresses 10 to 17) of the buffer memory?	Find out why a digital value outside the set range is written to the digital value setting area of the channel that corresponds to the non-zero set value check code storage area. Then, take corrective action and use the error reset flag to clear the set value check code storage area.

POINT

If all of the troubleshooting checks do not show problems, or if the prescribed corrective measures do not solve the problem, the A68DAV/DAI hardware might be faulty.

Consult a Mitsubishi representative.

APPENDICES

APPENDIX 1 Comparison with Other D-A Converter Modules

Table 1.1 shows the comparison of A68DAV/DAI and other D-A converter modules.

Table 1.1 Comparison List


Item		Specifications			
		A62DA	A62DA-S1	A616DAV/A616DAI	A68DAV/A68DAI
Digital input *2	Voltage	±2000	0 to +4000	-4000 to 4000	Maximum -12000 to 12000 (Varies according to resolution setting)
	Current	±1000		0 to 4000	Maximum 0 to 12000 (Varies according to resolution setting)
Analog output	Voltage	-10 to 0 to +10 VDC (External load resistance : 500 Ω to 1 MΩ)		-10 to 0 to 10 VDC / -5 to 0 to 5 VDC (External load resistance: 2 KΩ to 1 MΩ)	-10 to 0 to 10 VDC (External load resistance: 2 KΩ to 1 MΩ)
	Current	-20 to 0 to 20 mADC (External load resistance: 0 Ω to 600 Ω)	0 to 20 mADC (External load resistance: 0 Ω to 600 Ω)	0 to 20 mADC (External load resistance: 0 Ω to 600 Ω)	
Maximum resolution	Voltage	5 mV (1/2000)	1 to 5 V : 1 mV (1/4000) 0 to 5 V : 1.25 mV (1/4000) 0 to 10 V : 2.5 mV (1/4000)	-10 to 0 to 10 V : 1.30 mV (1/4000) -5 to 0 to 5 V : 0.65 mV (1/4000)	2.5 mV (1/4000) 1.25 mV (1/8000) 0.83 mV (1/12000) } Selectable
	Current	20 μA (1/1000)	4 to 20 mA : 4 μA (1/4000) 0 to 20 mA : 5 μA (1/4000)	2.64 μA (1/4000)	5 μA (1/4000) 2.5 μA (1/8000) 1.6 μA (1/12000) } Selectable
Overall accuracy (Precision related to the maximum value)		Within ±1.0%		Within ±0.6%	Within ±1.0%
Number of channels of analog output		2 channels/module		16 channels/module	8 channels/module
Conversion time		Within 15 ms/2 channels (same with 1 channel)		0.5 ms/channel	Within 40 ms/8channels (same with 1 channel)
Absolute maximum output	Voltage	±12 V	0 to 12 V	±12 V	±12 V
	Current	±28 mA	0 to 28 mA	0 to 28 mA	0 to 28 mA
Conversion method		2-channel simultaneous scanning		Scanning by each channel	8 channels simultaneous scan method
Offset/Gain adjustment		Adjustable without using offset/gain adjusting knobs			
Insulation method	Between input terminal and PLC	Photocoupler insulation			
	Between channels	Not insulated			
Output HOLD/CLEAR setting at STOP of PLC		Disabled	Enabled		
Channel designation of D-A conversion		Batch designation of all channels with output enable flag		Designation by each channel by setting of analog output enable/disable channel	
Designation of D-A conversion enable/disable with output enable flag		Batch designation of all channels			Designation by each channel
External power supply	Voltage	24 VDC		±15 VDC	24 VDC
	Current	0.35 A		+15 V:0.2 A, -15 V:0.17 A (DAV)	0.2 A (DAV)
				+15 V:0.53 A, -15 V: 0.125 A (DAI)	0.4 A (DAI)

*1 ——— In the columns of the A616DAV/A616DAI and A68DAV/A68DAI where the voltage and current areas are shown, values in the voltage area indicate specification of the voltage converter module (A[]DAV), and those in the current area indicate specification of the current converter module (A[]DAI).

*2 ——— Digital input values that allow the analog output value of a practicable range to be obtained are specified.


APPENDIX 2 Dimensions

2.1 A68DAV



Unit : mm (in)

2.2 A68DAI



WARRANTY

Please confirm the following product warranty details before starting use.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the dealer or Mitsubishi Service Company. Note that if repairs are required at a site overseas, on a detached island or remote place, expenses to dispatch an engineer shall be charged for.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not possible after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of chance loss and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to damages caused by any cause found not to be the responsibility of Mitsubishi, chance losses, lost profits incurred to the user by Failures of Mitsubishi products, damages and secondary damages caused from special reasons regardless of Mitsubishi's expectations, compensation for accidents, and compensation for damages to products other than Mitsubishi products and other duties.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi MELSEC programmable logic controller, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the programmable logic controller device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi general-purpose programmable logic controller has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or National Defense purposes shall be excluded from the programmable logic controller applications.

Note that even with these applications, if the user approves that the application is to be limited and a special quality is not required, application shall be possible.

When considering use in aircraft, medical applications, railways, incineration and fuel devices, manned transport devices, equipment for recreation and amusement, and safety devices, in which human life or assets could be greatly affected and for which a particularly high reliability is required in terms of safety and control system, please consult with Mitsubishi and discuss the required specifications.

HEADQUARTERS

EUROPE
MITSUBISHI ELECTRIC EUROPE B.V.
 German Branch
 Gothaer Straße 8
D-40880 Ratingen
 Phone: +49 (0) 21 02 / 486-0
 Fax: +49 (0) 21 02 / 4 86-1 12
 e mail: megfamail@meg.mee.com

FRANCE
MITSUBISHI ELECTRIC EUROPE B.V.
 French Branch
 25, Boulevard des Bouvets
F-92741 Nanterre Cedex
 Phone: +33 1 55 68 55 68
 Fax: +33 1 49 01 07 25
 e mail: factory.automation@fra.mee.com

ITALY
MITSUBISHI ELECTRIC EUROPE B.V.
 Italian Branch
 Via Paracelso 12
I-20041 Agrate Brianza (MI)
 Phone: +39 039 6053 1
 Fax: +39 039 6053 312
 e mail: factory.automation@it.mee.com

SPAIN
MITSUBISHI ELECTRIC EUROPE B.V.
 Spanish Branch
 Carretera de Rubí 76-80
E-08190 Sant Cugat del Vallés
 Phone: +34 9 3 / 565 3131
 Fax: +34 9 3 / 589 2948
 e mail: industrial@sp.mee.com

UK
MITSUBISHI ELECTRIC EUROPE B.V.
 UK Branch
 Travellers Lane
GB-Hatfield Herts. AL10 8 XB
 Phone: +44 (0) 1707 / 27 61 00
 Fax: +44 (0) 1707 / 27 86 95

JAPAN
MITSUBISHI ELECTRIC CORPORATION
 Office Tower "Z" 14 F
 8-12,1 chome, Harumi Chuo-Ku
Tokyo 104-6212
 Phone: +81 3 / 622 160 60
 Fax: +81 3 / 622 160 75

USA
MITSUBISHI ELECTRIC AUTOMATION
 500 Corporate Woods Parkway
Vernon Hills, IL 60061
 Phone: +1 847 / 478 21 00
 Fax: +1 847 / 478 22 83

EUROPEAN REPRESENTATIVES

AUSTRIA
GEVA GmbH
 Wiener Straße 89
A-2500 Baden
 Phone: +43 (0) 2252 / 85 55 20
 Fax: +43 (0) 2252 / 488 60
 E mail: office@geva.co.at

BELGIUM
 Getronics b.v.
 Control Systems
 Pontbeeklaan 43
B-1731 Asse-Zellik
 Phone: +32 (0) 2 / 4 67 17 51
 Fax: +32 (0) 2 / 4 67 17 45
 E mail: infoautomation@getronics.com

BULGARIA
TELECON CO.
 4, A. Ljapchev Blvd.
BG-1756 Sofia
 Phone: +359 92 / 97 44 05 8
 Fax: +359 92 / 97 44 06 1

CROATIA
INEA CR d.o.o.
 Drvinje 63
HR-10000 Zagreb
 Phone: +385 (0)1/ 36 67 140
 Fax: +385 (0)1/ 36 67 140

CZECHIA
 AutoCont
 Control Systems s.r.o.
 Nemocnici 12
CZ-702 00 Ostrava 2
 Phone: +420 (0) 69 / 615 21 11
 Fax: +420 (0) 69 / 615 21 12
 E mail: petr.pustovka@autocont.cz

DENMARK
 louis pulsens
 Geminivej 32
DK-2670 Greve
 Phone: +45 (0) 43 / 95 95 95
 Fax: +45 (0) 43 / 95 95 91
 E mail: l pia@lpmail.com

ESTONIA
 UTU Elektrotehnika AS
 Pärnu mnt.160i
EE-11317 Tallinn
 Phone: +372 6 / 51 72 80
 Fax: +372 6 / 51 72 88
 E mail: utu@utu.ee

FINLAND
 Beijer Electronics OY
 Elannontie 5
FIN-01510 Vantaa
 Phone: +358 (0) 9 / 615 20 11
 Fax: +358 (0) 9 / 615 20 500
 E mail: info@elc.beijer.fi

GREECE
 UTECO A.B.E.E.
 5, Mavrogenous Str.
GR-18542 Piraeus
 Phone: +30 10 / 42 10 050
 Fax: +30 10 / 42 12 033
 E-mail: —

IRELAND
MITSUBISHI ELECTRIC EUROPE B.V. – Irish Branch
 Westgate Business Park
IRL-Dublin 24
 Phone: +353 (0) 1 / 419 88 00
 Fax: +353 (0) 1 / 419 88 90
 E mail: sales.info@meuk.mee.com

LETLAND
POWEL SIA
 Lienes iela 28
LV-1009 Riga
 Phone: +371 784 / 22 80
 Fax: +371 784 / 22 81
 E-mail: utu@utu.lv

EUROPEAN REPRESENTATIVES

LITHUANIA
UTU POWEL UAB
 Savanoriu pr. 187
LT-2053 Vilnius
 Phone: +370 23 22 980
 Fax: +370 23 22 980
 E-mail: utu@utu.lv

NETHERLANDS
 Getronics b.v.
 Control Systems
 Donauweg 2 B
NL-1043 AJ Amsterdam
 Phone: +31 (0) 20 / 587 67 00
 Fax: +31 (0) 20 / 587 68 39
 E-mail: info.gia@getronics.com

NORWAY
 Beijer Electronics AS
 Teglverksveien 1
N-3002 Drammen
 Phone: +47 (0) 32 / 24 30 00
 Fax: +47 (0) 32 / 84 85 77
 E mail: info@elc.beijer.no

POLAND
 MPL Technology SP. z.o.o
 ul. Sliczna 36
PL-31-444 Kraków
 Phone: +48 (0) 12 / 632 28 85
 Fax: +48 (0) 12 / 632 47 82
 E-mail: krakow@mpl.pl

ROMANIA
 Sirius
 Trading & Services srl
 Bd. Lacul Tei nr. 1 B
RO-72301 Bucuresti 2
 Phone: +40 (0) 1 / 201 7147
 Fax: +40 (0) 1 / 201 7148
 E-mail: sirius_t_s@fx.ro

SLOVAKIA
 ACP AUTOCOMP a.s.
 Chalupkova 7
SK-81109 Bratislava
 Phone: +421 7 52 92 22 54
 Fax: +421 7 52 92 22 48
 E mail: info@acp-autocomp.sk

SLOVENIA
 INEA d.o.o.
 Ljubljanska 80
SI-1230 Domžale
 Phone: +386 (0) 17 21 80 00
 Fax: +386 (0) 17 24 16 72
 E mail: inea@inea.si

SWEDEN
 Beijer Electronics AB
 Box 426
S-20124 Malmö
 Phone: +46 (0) 40 / 35 86 00
 Fax: +46 (0) 40 / 93 23 02
 E mail: info@beijer.se

SWITZERLAND
 ECONOTEC AG
 Postfach 282
CH-8309 Nürensdorf
 Phone: +41 (0) 1 / 838 48 11
 Fax: +41 (0) 1 / 838 48 12
 E mail: info@econotec.ch

TURKEY
 GTS
 Darülaceze Cad. No. 43A KAT: 2
TR-80270 Okmeydani-Istanbul
 Phone: +90 (0) 212 / 320 1640
 Fax: +90 (0) 212 / 320 1649
 E mail: gts@turk.net

MIDDLE EAST REPRESENTATIVE

ISRAEL
TEXEL Electronics LTD.
 Rehov Hamerkava 19
IL-42160 Netanya
 Phone: +972 (0) 9 / 863 08 91
 Fax: +972 (0) 9 / 885 24 30
 e mail: texel_me@netvision.net.il

EURASIAN REPRESENTATIVES

RUSSIA
AVTOMATIKA SEVER
 Krapivnij Per. 5, Of. 402
RUS-194044 St Petersburg
 Phone: +7 812 / 325 36 53
 Fax: +7 812 11 83 239
 E-mail: —

RUSSIA
 CONSYS
 Promyshlennaya St. 42
RUS-198099 St Petersburg
 Phone: +7 812 / 325 36 53
 Fax: +7 812 / 325 36 53
 E-mail: consys@consys.spb.ru

RUSSIA
 NPP Uralelektra
 Sverdlova 11A
RUS-620027 Ekaterinburg
 Phone: +7 34 32 / 53 27 45
 Fax: +7 34 32 / 53 24 61
 E-mail: elektra@etel.ru

RUSSIA
 STC Drive Technique
 Poslannikov per., 9, str.1
RUS-107005 Moscow
 Phone: +7 095 / 786 21 00
 Fax: +7 095 / 786 21 01
 E-mail: info@privod.ru

UKRAINE
 JV-CSC Automation
 15, Marina Raskovoyi St.
U-02002 Kiev
 Phone: +380 44 / 238 83 16
 Fax: +380 44 / 238 83 17
 E-mail: mkl@csc-a.kiev.ua

BELARUS
 TEHNIKON
 Oktjabrskaya 16/5, Ap 704
BY-220030 Minsk
 Phone: +375 (0)17/ 22 75 704
 Fax: +375 (0)17/ 22 76 669
 E-mail: tehnikon@belsonet.net

AFRICAN REPRESENTATIVE

SOUTH AFRICA
 Circuit Breaker
 Industries Ltd.
 Private Bag 2016
ZAF-1600 Isando
 Phone: +2711 928 2000
 Fax: +2711 392 2354
 e mail: cbi@cbi.co.za