


» VITA 57 «



Development Kit User's Guide

SD.DT.F79-0e - May 2011

Revision History

Publication Title:		Development Kit User's Guide.	
Doc. ID:		SD.DT.F79-0e	
Rev.	Brief Description of Changes		Date of Issue
0e	Initial Version		May 2011

Copyright © 2011 Kontron AG. All rights reserved. All data is for information purposes only and not guaranteed for legal purposes. Information has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. Kontron and the Kontron logo and all other trademarks or registered trademarks are the property of their respective owners and are recognized. Specifications are subject to change without notice.

Proprietary Note

This document contains information proprietary to Kontron. It may not be copied or transmitted by any means, disclosed to others, or stored in any retrieval system or media without the prior written consent of Kontron or one of its authorized agents.

The information contained in this document is, to the best of our knowledge, entirely correct. However, Kontron cannot accept liability for any inaccuracies or the consequences thereof, or for any liability arising from the use or application of any circuit, product, or example shown in this document.

Kontron reserves the right to change, modify, or improve this document or the product described herein, as seen fit by Kontron without further notice.

Trademarks

This document may include names, company logos and trademarks, which are registered trademarks and, therefore, proprietary to their respective owners.

Environmental Protection Statement

This product has been manufactured to satisfy environmental protection requirements where possible. Many of the components used (structural parts, printed circuit boards, connectors, batteries, etc.) are capable of being recycled.

Final disposition of this product after its service life must be accomplished in accordance with applicable country, state, or local laws or regulations.



Environmental protection is a high priority with Kontron.

Kontron follows the DEEE/WEEE directive.

You are encouraged to return our products for proper disposal.

The Waste Electrical and Electronic Equipment (WEEE) Directive aims to:

- reduce waste arising from electrical and electronic equipment (EEE)
- make producers of EEE responsible for the environmental impact of their products, especially when they become waste
- encourage separate collection and subsequent treatment, reuse, recovery, recycling and sound environmental disposal of EEE
- improve the environmental performance of all those involved during the lifecycle of EEE

Conventions

This guide uses several types of notice: Note, Caution, ESD.



Note: this notice calls attention to important features or instructions.



Caution: this notice alert you to system damage, loss of data, or risk of personal injury.



ESD: This banner indicates an Electrostatic Sensitive Device.

All numbers are expressed in decimal, except addresses and memory or register data, which are expressed in hexadecimal. The prefix `0x` shows a hexadecimal number, following the `C` programming language convention.

The multipliers `k`, `M` and `G` have their conventional scientific and engineering meanings of $*10^3$, $*10^6$ and $*10^9$ respectively. The only exception to this is in the description of the size of memory areas, when `K`, `M` and `G` mean $*2^{10}$, $*2^{20}$ and $*2^{30}$ respectively.



When describing transfer rates, `k` `M` and `G` mean $*10^3$, $*10^6$ and $*10^9$ *not* $*2^{10}$ $*2^{20}$ and $*2^{30}$.

In PowerPC terminology, multiple bit fields are numbered from 0 to n, where 0 is the MSB and n is the LSB. PCI and CompactPCI terminology follows the more familiar convention that bit 0 is the LSB and n is the MSB.

Signal names ending with an asterisk (*) or a hash (#) denote active low signals; all other signals are active high.

Signal names follow the PICMG 2.0 R3.0 CompactPCI Specification and the PCI Local Bus 2.3 Specification.

For Your Safety

Your new Kontron product was developed and tested carefully to provide all features necessary to ensure its compliance with electrical safety requirements. It was also designed for a long fault-free life. However, the life expectancy of your product can be drastically reduced by improper treatment during unpacking and installation. Therefore, in the interest of your own safety and of the correct operation of your new Kontron product, you are requested to conform with the following guidelines.

High Voltage Safety Instructions



Warning!

All operations on this device must be carried out by sufficiently skilled personnel only.



Caution, Electric Shock!

Before installing a not hot-swappable Kontron product into a system always ensure that your mains power is switched off. This applies also to the installation of piggybacks. Serious electrical shock hazards can exist during all installation, repair and maintenance operations with this product. Therefore, always unplug the power cable and any other cables which provide external voltages before performing work.

Special Handling and Unpacking Instructions



ESD Sensitive Device!

Electronic boards and their components are sensitive to static electricity. Therefore, care must be taken during all handling operations and inspections of this product, in order to ensure product integrity at all times

Do not handle this product out of its protective enclosure while it is not used for operational purposes unless it is otherwise protected.

Whenever possible, unpack or pack this product only at EOS/ESD safe work stations. Where a safe work station is not guaranteed, it is important for the user to be electrically discharged before touching the product with his/her hands or tools. This is most easily done by touching a metal part of your system housing.

It is particularly important to observe standard anti-static precautions when changing piggybacks, ROM devices, jumper settings etc. If the product contains batteries for RTC or memory backup, ensure that the board is not placed on conductive surfaces, including anti-static plastics or sponges. They can cause short circuits and damage the batteries or conductive circuits on the board.

General Instructions on Usage

In order to maintain Kontron's product warranty, this product must not be altered or modified in any way. Changes or modifications to the device, which are not explicitly approved by Kontron and described in this manual or received from Kontron's Technical Support as a special handling instruction, will void your warranty.

This device should only be installed in or connected to systems that fulfill all necessary technical and specific environmental requirements. This applies also to the operational temperature range of the specific board version, which must not be exceeded. If batteries are present, their temperature restrictions must be taken into account.

In performing all necessary installation and application operations, please follow only the instructions supplied by the present manual.

Keep all the original packaging material for future storage or warranty shipments. If it is necessary to store or ship the board, please re-pack it as nearly as possible in the manner in which it was delivered.

Special care is necessary when handling or unpacking the product. Please consult the special handling and unpacking instruction on the previous page of this manual.

Table Of Contents

Chapter 1 - Introduction	1
1.1 Prerequisites	1
1.2 Use cases	1
Chapter 2 - Development	2
2.1 FPGA Kontron Source Code	2
2.2 FPGA Code Compilation	4
Chapter 3 - Deployment	7
3.1 Upload User Flash with Software Tool from Linux Prompt (Binary file)	7
3.2 Upload User Flash with JTAG Probe (mcs file)	7
3.3 Upload Flash on FMC	7
Chapter 4 - Troubleshooting	8
4.1 Configuration Check	8
4.2 FPGA Check	8
4.3 FMC EEPROM Check	9
4.4 FMC IOs Check	9
4.4.1 FMC GPIO signals	9
4.4.2 FMC TXn/RXn signals	11
4.4.2.1 <i>Enable buffers</i>	12
4.4.2.2 <i>Test a channel</i>	12
4.5 Low Level Debug with IO Command	14
Chapter 5 - Additional Information	16
5.1 Loopback Connector on FMC-SER0 Front Panel	16
5.2 IO Routing with a VM6250 SBC board as FMC Carrier	18

Chapter 1 - Introduction

1.1 Prerequisites

- Knowledges and practices of the xilinx development and design tools like Ise Design Suite version 11.1.
- User's knowledges and practices of Linux: the drivers and tests tools (binaries and sources) delivered as examples, are available for Linux distributions and are coded in C and python language.
- Modifying some FPGA code IP's like I2C, SPI is highly inadvisable. All modification will be done at customer's own risks. I2C and SPI IPs were dedicated to Kontron boards so any changes could break some functionalities.

1.2 Use cases

This documents meet the following cases:


- New FPGA application development.
- New FPGA application deployment.
- New FPGA application test.
- Troubleshooting. All of those cases will be developed hereafter.

Chapter 2 - Development

The following chapters will describe an example of a FPGA application development and how to use the tools to generate an FPGA image.


2.1 FPGA Kontron Source Code

The VITA 57 project example file tree is the following:



The entry point of the Kontron source code is the file Topserial.v describing a VITA 57 implementation example.

The following shows the FPGA sources files:



Now, you could add your Verilog files and libraries, modify the current files to match your application. You will find hereafter the snapshot of the VM6250 VITA 57 project as example.

2.2 FPGA Code Compilation

The following is an example of compilation based on VM6250 VITA 57 case.

➤ You will find hereafter the snapshot of the VM6250 VITA 57 project as example:

The screenshot displays the ISE Project Navigator interface for the VM6250 project. The main window shows the Design Summary, which includes a Project Status table, a Partition Summary, and a Device Utilization Summary table.

VM6250 Project Status (02/18/2011 - 17:04:11)

Project File: VM6250.ise	Implementation State: Programming File Generated
Module Name: Topserial	Errors: No Errors
Target Device: xc5vbx20t-2ff323	Warnings: 4056 Warnings
Product Version: ISE 11.1	Routing Results: All Signals Completely Routed
Design Goal: Balanced	Timing Constraints: All Constraints Met
Design Strategy: Xilinx Default (unlocked)	Final Timing Score: 0 (Setup: 0, Hold: 0, Component Switching Limit: 0) [Timing Report]


VM6250 Partition Summary

No partition information was found.


Device Utilization Summary

Slice Logic Utilization	Used	Available	Utilization	Note(s)
Number of Slice Registers	5,364	12,480	42%	
Number used as Flip Flops	5,360			
Number used as Latches	4			
Number of Slice LUTs	4,530	12,480	36%	
Number used as logic	4,267	12,480	34%	
Number using O6 output only	4,089			
Number using O5 output only	83			
Number using O5 and O6	95			
Number used as Memory	238	3,360	7%	
Number used as Dual Port RAM	42			

- Open the ISE Design suite and select your project:



- Select your application dedicated file into the hierarchy window (here, Topserial.v), then right click on “Generate program file” into the process window and click on “Run” or “ReRun” ... to generate the “bit” or “bin” or both files file (You can select to generate several kind of files using the processes properties into the process menu).



- The generation process is launched, if no errors appear, "bit" file will be generated into Worklib directory.

Chapter 3 - Deployment

On Kontron design, the Flash containing the FPGA code is fitted on the CPU Board near the FPGA chip. This flash contains a rescue FPGA image used to check the health of the Flash/FPGA/FMC ensemble. The development kit provides the same image as the sample user application. Once the customer application generated, there are several ways to upload the flash.

3.1 Upload User Flash with Software Tool from Linux Prompt (Binary file)

Uploading the flash from the development kit platform OS is done using a Linux command line tool. Refer to your platform VITA 57 BSP for more information. This tool requires a binary file to upload. The ISE Design suite generate mcs files used to upload flash with JTAG probe (see section 3.2 page 7). A tool is needed to convert mcs file to bin files that can be uploaded; refer to your platform VITA 57 BSP for more information. The flash upload is also platform dependant so refer also to Your VITA 57 BSP documentation for more informations about it.

3.2 Upload User Flash with JTAG Probe (mcs file)

At first, a “mcs” image must be generated, so use the “Impact” tool from the ISE Design Suite to create a “mcs” file from the “bit” file obtained by the image generation. This could be done only for rescue images in case of troubleshooting.



Upload a FPGA image when the rescue mode is activated will break the rescue image

So to upload the user FPGA image using JTAG probe:

- Check first the user image is activated, then check the upload via JTAG is allowed: refer to the mother board (SBC or Carrier) User's Guide to set the jumper or dip switches.
- Plug the JTAG probe to the JTAG connector.
- Do not boot the board under OS, so enter BIOS/firmware/U-Boot.
- Using “Impact” tool from ISE Design Suite, upload the new image.
- Once done, power cycle the board.

3.3 Upload Flash on FMC

The VITA 57 standard also allows the flash containing the FPGA code to be on the FMC. Kontron Modular Computers does not to implement flash on current FMC so this feature is not available in the kit.

Chapter 4 - Troubleshooting

In case of troubleshooting, the user should first revert to the delivered configuration in order to check the health of the VITA 57 kit.

- Plug the FMC (FMC-SER0) delivered with the VITA 57 package in the FMC slot.
- Activate the FPGA rescue image; to proceed, refer to the mother board (SBC or Carrier) User's Guide. For example, VME development kit using a VM6250 board, bit4 of switch5 shall be set to ON.
- Double check flash write protection. Refer to the mother board (SBC or Carrier) User's Guide to enable/disable flashes write protection through dip switches or jumper.
- Boot the board and get the user and password from the VITA 57 BSP documentation of the board and log in.

4.1 Configuration Check

This is a basic verification of the installed software:

```
# rpm -qa | grep VITA57
VITA57_BSP-1.0-2.6.25_10356.vm6250.fc9.ppc.smp.11004.ppc
```

```
# rpm -qa | grep kernel
kernel-smp-devel-2.6.25-10356.vm6250.fc9.ppc
kernel-smp-2.6.25-10356.vm6250.fc9.ppc
kernel-bootwrapper-2.6.25-09135.vm6250.fc9.ppc
kernel-devel-2.6.25-09135.vm6250.fc9.ppc
kernel-headers-2.6.25-10355.vm6250.fc9.ppc
```

4.2 FPGA Check

Launch the following command to check the FPGA presence:

```
# lspci | grep -i teknor
0000:04:00.0 Memory controller: Teknor Industrial Computers Inc Unknown device
9050 (rev 01)
```

If there is no output, the FPGA is not reachable; it means that some:

- The FPGA fails and could not fetch the rescue image from the flash.
- The rescue flash is not available.
- The rescue image might be corrupted.
- PCI Xpress accesses fail.

4.3 FMC EEPROM Check

In order to access the FMC EEPROM run the following command to display the VPD:

```
# e2fmc-v-W
Product Name    [My Board Product Name]
Serial Number   [My Board Serial Number]
Part Number     []
```

If the output is the following:

```
Cannot read eeprom !
```

The FMC EEPROM could not be reach and some configurations must have failed.

4.4 FMC IOs Check

This check will be done with a loopback wired connector plugged on the FMC-SER0 front panel in order to verify the IOs available on this front panel (FMC GPIOn and FMC TXn/RXn signals).

4.4.1 FMC GPIOn signals

Set odd FMC GPIOs (GPIO1,3,5,7,9) as outputs, others as inputs:

```
# gpio -c 9 -s GPIO_Control -v 0x155
```

Set output GPIOs to 1:

```
# gpio -c 9 -s GPIO_DataOut -v 0x155
```

Check the GPIO levels: all must be at level 1 (because they are outputs at level 1, or because they are inputs connected to the outputs).

```
# gpio -c 9 -g GPIO_In
GPIO_In -> 0x000003FF
```

Set output GPIOs to 0:

```
# gpio -c 9 -s GPIO_DataOut -v 0x0
```

Check the GPIO levels: all must be at level 0 (because they are outputs at level 0, or because they are inputs connected to the outputs)

```
# gpio -c 9 -g GPIO_In
GPIO_In -> 0x00000000
#
```

Set even FMC GPIOs (GPIO2,4,6,8,10) as outputs, others as inputs:

```
# gpio -c 9 -s GPIO_Control -v 0x2aa
```

Set output GPIOs to 1:

```
# gpio -c 9 -s GPIO_DataOut -v 0x2aa
```

Check the GPIO levels: all must be at level 1 (because they are outputs at level 1, or because they are inputs connected to the outputs).

```
# gpio -c 9 -g GPIO_In
GPIO_In -> 0x000003FF
```

Set output GPIOs to 0:

```
# gpio -c 9 -s GPIO_DataOut -v 0x0
```

Check the GPIO levels: all must be at level 0 (because they are outputs at level 0, or because they are inputs connected to the outputs)

```
# gpio -c 9 -g GPIO_In
GPIO_In -> 0x00000000
#
```



> To see the current value of all registers of a channel (binary and hex format), use the -u option. For example:

```
# gpio -c 9 -u
*****
Channel: 9 => 10 GPIOs
*****
GPIO_Control      XXXXXXXXXXXXXXXXXXXXXXX1010101010 0x00002AA
GPIO_DataOut      XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
GPIO_In           XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
GPIO_IntMask      XXXXXXXXXXXXXXXXXXXXXXX1111111111 0x00003FF
GPIO_IntPolarity  XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
GPIO_IntMode      XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
GPIO_IntToggle    XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
GPIO_IntStatus    XXXXXXXXXXXXXXXXXXXXXXX000000000 0x0000000
*****
GPIO_GlobalStatus 00000000000000000000000000000000
*****
```


- it is also possible to set a register and read back the value of all registers in one command. For example the following lines :

```
# gpio -c 9 -s GPIO_DataOut -v 0x2aa
# gpio -c 9 -g GPIO_In
GPIO_In -> 0x000003FF
```

can be replaced with:

```
# gpio -c 9 -u -s GPIO_DataOut -v 0x2aa
*****
Channel: 9 => 10 GPIOs
*****
GPIO_Control          XXXXXXXXXXXXXXXXXXXXXXX10101010 0x00002AA
GPIO_DataOut          XXXXXXXXXXXXXXXXXXXXXXX10101010 0x00002AA
GPIO_In               XXXXXXXXXXXXXXXXXXXXXXX11111111 0x00003FF
GPIO_IntMask          XXXXXXXXXXXXXXXXXXXXXXX11111111 0x00003FF
GPIO_IntPolarity      XXXXXXXXXXXXXXXXXXXXXXX00000000 0x0000000
GPIO_IntMode          XXXXXXXXXXXXXXXXXXXXXXX00000000 0x0000000
GPIO_IntToggle        XXXXXXXXXXXXXXXXXXXXXXX00000000 0x0000000
GPIO_IntStatus        XXXXXXXXXXXXXXXXXXXXXXX00000000 0x0000000
*****
GPIO_GlobalStatus    00000000000000000000000000000000
*****
```

- for more info on "GPIO" command:

```
# gpio -h
```

4.4.2 FMC TXn/RXn signals

These signals can be set for RS232 or RS422/485 mode.



On FMC-SER0 PCB B:

- the TXn buffers are enabled by the DXEN (for TX1 to TX14) and DXEN1516 (for TX15 and TX16) signals, when set to level 1.
- the RS232 or RS422/485 mode is set by switches and can be overridden by software with LED1R_SW1 (TX1/RX1 to TX4/RX4), LED1G_SW2 (TX5/RX5 to TX8/RX8), LED2R_SW3 (TX9/RX9 to TX12/RX12), and LED2G_SW4 (TX13/RX13 to TX16/RX16). Level 1 for RS422/485; 0 for RS232.

On FMC-SER0 PCB A:

- all TXn buffers are enabled by the DXEN signal when set to level 1 - DXEN1516 is called MODE and selects RS232 or RS422/485 for all TXn. Level 1 for RS422/485; 0 for RS232.

The procedure below assumes that a FMC-SER0 PCB B is used.

4.4.2.1 Enable buffers

Set DXEN and DXEN1516 as outputs:

```
# gpio -c 8 -s GPIO_Control -v 0x3
```

Set DXEN and DXEN1516 to level 1 to enable all TXn outputs:

```
# gpio -c 8 -s GPIO_DataOut -v 0x3
```



the command above is suitable for FMC-SER0 PCB B. On FMC-SER0 PCB A, the RS232 or RS422/485 mode is controlled by DXEN1516 for all TXn/RXn:

> to set to RS232:

```
# gpio -c 8 -s GPIO_DataOut -v 0x1
```

> to set to RS422/485:

```
# gpio -c 8 -s GPIO_DataOut -v 0x3
```

4.4.2.2 Test a channel

The test below is done on channel 0: TX1/RX1, TX2/RX2. It must also be done on other channels (1 to 7) by replacing the "-c 0" with "-c 1" to "-c 7".

Set TX signals as outputs (TX1 and TX2)

```
# gpio -c 0 -s GPIO_Control -v 0xa
```

Check TX/RX signals when configured for RS422/485. The level set on TX1 must be also read on RX1, but setting a level on TX2 does not change RX2 as we are in differential mode: TX1/TX2 and RX1/RX2 are the same pair.

```
# gpio -c 0 -s GPIO_DataOut -v 0x8 # TX1=1, TX2=0
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=1, TX2=RX2=0
GPIO_In -> 0x00000009
# gpio -c 0 -s GPIO_DataOut -v 0x2 # TX1=0, TX2=1
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=RX2=0, TX2=1
GPIO_In -> 0x00000002
# gpio -c 0 -s GPIO_DataOut -v 0x0 # TX1=0, TX2=0
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=TX2=RX2=0
GPIO_In -> 0x00000000
#
```

Check TX/RX signals when configured for RS232. The level set on TX1 must be also read on RX1, and the level set on TX2 must be also read on RX2 (TX1/TX2 and RX1/RX2 are independant).

```
# gpio -c 0 -s GPIO_DataOut -v 0x8 # TX1=1, TX2=0
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=1, TX2=RX2=0
GPIO_In -> 0x00000009
# gpio -c 0 -s GPIO_DataOut -v 0x2 # TX1=0, TX2=1
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=0, TX2=RX2=1
GPIO_In -> 0x00000006
# gpio -c 0 -s GPIO_DataOut -v 0x0 # TX1=0, TX2=0
# gpio -c 0 -g GPIO_In             # must read TX1=RX1=TX2=RX2=0
GPIO_In -> 0x00000000
#
```

4.5 Low Level Debug with IO Command

This command can be used to read/write FPGA registers. First, get the FPGA registers physical base address using "lspci -x":

```
0000:04:00.0 Memory controller: Teknor Industrial Computers Inc Unknown device
9050 (rev fe)
00: 59 10 50 90 06 00 10 00 fe 00 80 05 08 00 00 00
10: 04 00 00 80 00 00 00 00 00 08 00 80 00 00 00 00
20: 00 00 00 00 00 00 00 00 00 00 00 00 59 10 01 00
30: 00 00 00 00 40 00 00 00 00 00 00 00 42 01 00 00
```

The 32bit swapped address is stored in BAR2 at PCI configuration offset 0x18. In the example above, the address is: `swap32(0x00080080) = 0x80000800`

The examples below assume that FPGA registers are mapped at this address in physical memory.



When reading or writing 32bit data using "IO", the data has to be swapped. This does not apply to the address parameter; only to data.

Here is an example with TX1, TX2, RX1 and RX2 using a loopback connector on the FMC-SER0 front panel. Set VADJ to 3V3 in "REGIO general purpose" register at offset 0x380 (if not yet done) :

```
[root@localhost ~]# io -4 -w 0x80000b80 0x08000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000b80
80000b80: 08000000
```

Set signals controlling buffer output enable as outputs by setting channel 8 "GPIO control" register at offset 0x200 :

```
[root@localhost ~]# io -4 -w 0x80000a00 0x03000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000a00
80000a00: 03000000
```

Set signals controlling TX1 and TX2 as outputs by setting channel 0 "GPIO control" register at offset 0x000

```
[root@localhost ~]# io -4 -w 0x80000800 0x0a000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000800
80000800: 0a000000
```

Enable output of buffers by setting channel 8 "GPIO DataOut" register at offset 0x204:

```
[root@localhost ~]# io -4 -w 0x80000a04 0x01000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000a04
80000a04: 01000000
```

If FMC-SER0 is configured for RS422/485:

```
Set TX1 to 1 by setting channel 0 "GPIO DataOut" register at offset 0x004 - >
should reread TX1 = 1, but also RX1 = 1 because of loopback, in channel 0
"GPIO DataIn" register at offset 0x008
[root@localhost ~]# io -4 -w 0x80000804 0x08000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000808
80000808: 09000000
```

```
Set TX1 to 0 -> should reread TX1 = 0, but also RX1 = 0 because of loopback
[root@localhost ~]# io -4 -w 0x80000804 0x00000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000808
80000808: 00000000
[root@localhost ~]#
```

If FMC-SER0 is configured for RS232 :

```
Set TX1 = 1 and TX2 = 0 -> should reread TX1 = 1 and TX2 = 0, but also RX1 =
1 and RX2 = 0 because of loopback
[root@localhost ~]# io -4 -w 0x80000804 0x08000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000808
80000808: 09000000
```

```
Set TX1 = 0 and TX2 = 1 -> should reread TX1 = 0 and TX2 = 1, but also RX1 =
0 and RX2 = 1 because of loopback
[root@localhost ~]# io -4 -w 0x80000804 0x02000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000808
80000808: 06000000
[root@localhost ~]#
```

```
Set TX1 and TX2 to 0 -> should reread TX1 = TX2 = 0, but also RX1 = RX2 = 0
because of loopback
[root@localhost ~]# io -4 -w 0x80000804 0x00000000
[root@localhost ~]# io -4 -r -l 0x4 0x80000808
80000808: 00000000
```

Chapter 5 - Additional Information

5.1 Loopback Connector on FMC-SER0 Front Panel

This connector is to be plugged on the FMC-SER0 front panel connector to perform some tests on IOs and check that the hardware is OK.

Pin number (50 pin connector)	Signal	
1	GND1	Not connected
2	TX1	Connected to RX1
3	RX2	Connected to TX2
4	GND2	Not connected
5	TX3	Connected to RX3
6	RX4	Connected to TX4
7	GND3	Not connected
8	TX5	Connected to RX5
9	RX6	Connected to TX6
10	GND4	Not connected
11	TX7	Connected to RX7
12	RX8	Connected to TX8
13	GND5	Not connected
14	TX9	Connected to RX9
15	RX10	Connected to TX10
16	GND6	Not connected
17	TX11	Connected to RX11
18	RX12	Connected to TX12
19	GND7	Not connected
20	TX13	Connected to RX13
21	RX14	Connected to TX14
22	GND8	Not connected
23	TX15	Connected to RX15
24	RX16	Connected to TX16
25	GPIO10	1Kohms to GPIO9
26	GPIO9	Already connected
27	TX16	Already connected
28	GPIO8	1Kohms to GPIO7
29	RX15	Already connected

Pin number (50 pin connector)	Signal	
30	TX14	Already connected
31	GPIO7	Already connected
32	RX13	Already connected
33	TX12	Already connected
34	GPIO6	1Kohms to GPIO5
35	RX11	Already connected
36	TX10	Already connected
37	GPIO5	Already connected
38	RX9	Already connected
39	TX8	Already connected
40	GPIO4	1Kohms to GPIO3
41	RX7	Already connected
42	TX6	Already connected
43	GPIO3	Already connected
44	RX5	Already connected
45	TX4	Already connected
46	GPIO2	1Kohms to GPIO1
47	RX3	Already connected
48	TX2	Already connected
49	GPIO1	Already connected
50	RX1	Already connected

5.2 IO Routing with a VM6250 SBC board as FMC Carrier

FPGA pin	FMC connector pin from VM6250 (VITA57 / schematics)	FMC-SER 0 signal from VM6250	FMC-SER 0 I/O name	FMC-SER 0 signal to VM6250	FMC connector pin to VM6250 (VITA57 / schematics)	VM6250 PMCB_IO signal	VM6250 VME P2 connector pin	RTM J14 pin	Test loopback connector on RTM J14
N18	G6 / 57	LA0P	RX1	HA14P	J15 / 149	1	C1	1	to pin 2
M18	G7 / 67	LA0N	RX2	HA14N	J16/159	3	C2	3	to pin 4
L13	D9 / 84	LA1N	TX1	HA16P	E15 / 145	2	A1	2	
M14	D8 / 74	LA1P	TX2	HA16N	E16 / 155	4	A2	4	
H13	H7 / 68	LA2P	RX3	HA17P	K16 / 160	9	C5	9	to pin 10
J14	H8 / 78	LA2N	RX4	HA17N	K17 / 170	11	C6	11	to pin 12
G18	G10 / 97	LA3N	TX3	HA15P	F16 / 156	10	A5	10	
H17	G9 / 87	LA3P	TX4	HA15N	F17 / 166	12	A6	12	
H18	H10 / 98	LA4P	RX5	HA21P	K19 / 190	13	C7	13	to pin 14
J18	H11 / 108	LA4N	RX6	HA21N	K20 / 200	15	C8	15	to pin 16
H16	D12 / 114	LA5N	TX5	HA19P	F19 / 186	14	A7	14	
H15	D11 / 104	LA5P	TX6	HA19N	F20 / 196	16	A8	16	
J17	C10 / 93	LA6P	RX7	HA23P	K22 / 220	21	C11	21	to pin 22
K17	C11 / 103	LA6N	RX8	HA23N	K23 / 230	23	C12	23	to pin 24
K15	H14 / 138	LA7N	TX7	HB5P	E24 / 235	22	A11	22	
J15	H13 / 128	LA7P	TX8	HB5N	E25 / 245	24	A12	24	
L14	G12 / 117	LA8P	RX9	HB1P	J24 / 239	25	C13	25	to pin 26
K14	G13 / 127	LA8N	RX10	HB1N	J25 / 249	27	C14	27	to pin 28
L17	D15 / 144	LA9N	TX9	HB9P	E27 / 265	26	A13	26	
L18	D14 / 134	LA9P	TX10	HB9N	E28 / 275	28	A14	28	
N16	C14 / 133	LA10P	RX11	HB11P	J30 / 299	33	C17	33	to pin 34
M16	C15 / 143	LA10N	RX12	HB11N	J31 / 309	35	C18	35	to pin 36
M15	H17 / 168	LA11N	TX11	HB19P	E33 / 325	34	A17	34	
N15	H16 / 158	LA11P	TX12	HB19N	E34 / 335	36	A18	36	
N13	G15 / 147	LA12P	RX13	HB15P	J33 / 329	37	C19	37	to pin 38
M13	G16 / 157	LA12N	RX14	HB15N	J34 / 339	39	C20	39	to pin 40
P15	D18 / 174	LA13N	TX13	HB21P	E36 / 355	38	A19	38	
P14	D17 / 164	LA13P	TX14	HB21N	E37 / 365	40	A20	40	
R15	C18 / 173	LA14P	RX15 (4)	HB6P	K28 / 280	45	C23	45	to pin 46
R16	C19 / 183	LA14N	RX16 (4)	HB6N	K29 / 290	47	C24	47	to pin 48
N17	H20 / 198	LA15N	TX15 (4)	HB4P	F25 / 246	46	A23	46	
P18	H19 / 188	LA15P	TX16 (4)	HB4N	F26 / 256	48	A24	48	
F16	D20 / 194	LA17P	GPIO1	HA20P	E18 / 175	6	A3	6	1k to pin 8
G16	D21 / 204	LA17N	GPIO2	HA20N	E19 / 185	8	A4	8	
C15	C22 / 213	LA18P	GPIO3	HB3P	E21 / 205	18	A9	18	1k to pin 20
B15	C23 / 223	LA18N	GPIO4	HB3N	E22 / 215	20	A10	20	
A18	H22 / 218	LA19P	GPIO5	HB13P	E30 / 295	30	A15	30	1k to pin 32

FPGA pin	FMC connector pin from VM6250 (VITA57 / schematics)	FMC-SER 0 signal from VM6250	FMC-SER 0 I/O name	FMC-SER 0 signal to VM6250	FMC connector pin to VM6250 (VITA57 / schematics)	VM6250 PMCB_IO signal	VM6250 VME P2 connector pin	RTM J14 pin	Test loopback connector on RTM J14
A17	H23 / 228	LA19N	GPIO6	HB13N	E31 / 305	32	A16 (1)	32	
A11	G21 / 207	LA20P	GPIO7	HB2P	F22 / 216	42	A20	42	1k to pin 44
A12	G22 / 217	LA20N	GPIO8	HB2N	F23 / 226	44	A21	44	
B11	H25 / 248	LA21P	GPIO9	HB10P	K31 / 310	49	C25	49	1k to pin 50
C11	H26 / 258	LA21N	GPIO10	HB8P	F28 / 276	50	A25	50	
B13	G24 / 237	LA22P	GPIO11	HB10N	K32 / 320	51	C26	51	1k to pin 52
A13	G25 / 247	LA22N	GPIO12	HB8N	F29 / 286	52	A26	52	
B14	D23 / 224	LA23P	GPIO13	HB14P	K34 / 340	53	C27	53	1k to pin 55
A14	D24 / 234	LA23N	GPIO14	HB14N	K35 / 350	55	C28	55	
D13	H28 / 278	LA24P	GPIO15	HB12P	F31 / 306	54	A27	54	1k to pin 56
D14	H29 / 288	LA24N	GPIO16	HB12N	F32 / 316	56	A28	56	
E14	G27 / 267	LA25P	GPIO17	HB17P	K37 / 370	57	C29	57	1k to pin 59
F14	G28 / 277	LA25N	GPIO18	HB17N	K38 / 380	59	C30	59	
E15	D26 / 254	LA26P	GPIO19	HB20P	F37/366	58	A29	58	1k to pin 60
D15	D27 / 264	LA26N	GPIO20	HB20N	F38 / 376	60	A30	60	
E17	C26 / 253	LA27P	GPIO21	HB18P	J36/359	61	C31	61	1k to pin 63
E16	C27 / 263	LA27N	GPIO22	HB18N	J37 / 369	63	C32	63	
F18	H31 / 308	LA28P	GPIO23	HB16P	F34 / 336	62	A31	62	1k to pin 64
F17	H32 / 318	LA28N	GPIO24	HB16N	F35 / 346	64	A32	64	
N12	G18/177	LA16P	DXEN (2)						
M11	G19 / 187	LA16N	DXEN1516 (2)						
G14	G33 / 327	LA31P	LED1R_S W1 (3)						
G15	G34 / 337	LA31N	LED1G_S W2 (3)						
D12	G36 / 357	LA33P	LED2R_S W3 (3)						
E12	G37 / 367	LA33N	LED2G_S W4 (3)						
D18	G30 / 297	LA29P	CAN1_RX D (4)						
D17	G31 / 307	LA29N	CAN1_TX D (4)						
C18	H34/338	LA30P	CAN2_RX D (4)						
B18	H35 / 348	LA30N	CAN2_TX D (4)						
B16	H37 / 368	LA32P	CAN_STB						
A16	H38 / 378	LA32N	TB0201						
			GND	HA18P	J18 / 179	5	C3	5	

FPGA pin	FMC connector pin from VM6250 (VITA57 / schematics)	FMC-SER0 signal from VM6250	FMC-SER0 I/O name	FMC-SER0 signal to VM6250	FMC connector pin to VM6250 (VITA57 / schematics)	VM6250 PMCB_IO signal	VM6250 VME P2 connector pin	RTM J14 pin	Test loopback connector on RTM J14
			GND	HA18N	J19 / 189	7	C4	7	
			GND	HA22P	J21 / 209	17	C9	17	
			GND	HA22N	J22 / 219	19	C10	19	
			GND	HB7P	J27 / 269	29	C15	29	
			GND	HB7N	J28 / 279	31	C16(1)	31	
			GND	HB0P	K25 / 250	41	C21	41	
			GND	HB0N	K26 / 260	43	C22	43	

(1) :

- P2 pin A16 may be REAR2_RTS+ or HB13N depending on VX6060 equipment
- P2 pin C16 may be REAR1_RTS+ or HA7N depending on VX6060 equipment

(2) :

With FMC-SER0 PCB A :

- DXEN : enables TXn outputs when set to level 1
- DXEN1516 : is used as a MODE signal for all TXn/RXn buffers : RS422 or 485 when set to level 1; RS232 if set to 0

With FMC-SER0 PCB B : these signals control TXn outputs of buffers (mandatory for RS485 mode) :

level 1 : enabled

level 0 : disabled

- DXEN : TX1,TX2,TX3,TX4,TX5,TX6,TX7,TX8,TX9,TX10,TX11,TX12,TX13,TX14

- DXEN1516 : TX15/TX16 pair

(3) :

With FMC-SER0 PCB A : these signals are only used to drive the LEDs, and the mode of TXn/RXn buffers (232 or 422/485) is set by the MODE signal (DXEN1516)

With FMC-SER0 PCB B : these signals control the LEDs and also override the default mode of TXn/RXn buffers set by the switches :

level 1 : RS422 or 485

level 0 : RS232

- LED1R_SW1 : TX1, RX1, TX2, RX2, TX3, RX3, TX4, RX4

- LED1G_SW2 : TX5, RX5, TX6, RX6, TX7, RX7, TX8, RX8

- LED2R_SW3 : TX9, RX9, TX10, RX10, TX11, RX11, TX12, RX12

- LED2G_SW4 : TX13, RX13, TX14, RX14, TX15, RX15, TX16, RX16

(4) : depending on FMC-SER0 configuration :

- HB6P may be connected to RX15 or CAN1+

- HB6N may be connected to RX16 or CAN2+

- HB4P may be connected to TX15 or CAN1-

- HB4N may be connected to TX16 or CAN2-

MAILING ADDRESS

Kontron Modular Computers S.A.S.
150 rue Marcelin Berthelot - BP 244
ZI TOULON EST
83078 TOULON CEDEX - France

TELEPHONE AND E-MAIL

+33 (0) 4 98 16 34 00
sales@kontron.com
support-kom-sa@kontron.com

For further information about other Kontron products, please visit our Internet web site:
www.kontron.com.