



'Class 1' laser beam sensor safe for your eyes




Safe laser beam

This laser collimated beam sensor conforms to the Class 1 laser stipulated in IEC Publication 825 and JIS C 6802-1997. Hence, safety measures such as protective gear are not necessary.

Precise sensing in wide area

Sensing area: $15 \times 500 \text{ mm}$ $0.591 \times 19.685 \text{ in}$ Minimum sensing object: $\neq 0.1 \text{ mm}$ $\neq 0.004 \text{ in}$ Repeatability: $10 \ \mu \text{m} \ 0.394 \text{ mil or less}$



FDA Class I type LA-511


LA-511 conforms to FDA Class I.

FDA.

It is approved for use in U.S.A. by

Easy laser beam alignment

Four monitoring LEDs help you to easily align the emitter and the receiver.



Receiver front face




The monitoring system checks whether the incident beam falls evenly on all the four receiving elements in the receiver window.

Thru-bea

ight /

 $\overline{\nabla}$






The side view attachment (optional)


enables versatile mounting styles.

LA

Accurate positioning of orientation flat



Counting number of O-rings



Convenient laser sensor controller LA-C1

Simple digital setting

Fine adjustment can be easily done using the actual object while observing the digital display.

Large 3¹/₂ digit display

Easily visible 10 mm 0.394 in letter height display.

Auto-reference function

The set values can be automatically compensated for a change in the reference value by using an external signal.


Two types of operation modes

1 Hysteresis mode


2 Window comparator mode




Detecting cathode ray tube




Positioning gear on polishing machine



Detecting tablet displaced from pocket



Attitude of chip component




Operation theory

• The semiconductor laser diode and an advanced optical system realize an ideal collimated beam.



• The high precision APC circuit maintains constant laser beam output power.


The APC (Automatic Power Control) circuit maintains stable emission strength by a feedback technique. A uniform emission level is maintained in spite of temperature drift and/or supply voltage change.



High accuracy applications

• The sensor can be used for various applications due to its collimated laser beam.

Positioning



Detection at same degree of intrusion at any position (@, (B, C)) within the sensing range.

Presence detection



The path position of the sensing object need not be fixed.

Width discrimination



Even a minute difference can be reliably detected since the difference in the beam interruption is projected, as it is, on the receiving section.

Detecting amount of laser beam


 Emitter
 Receiver

 Image: Comparison of the second seco

Its wide laser beam senses the total object.

ORDER GUIDE

LA




Laser sensor controller

Appearance	Model No.	Output
DIN 72 × 72 mm 2.835 × 2.835 in	LA-C1	NPN open-collector transistor

Accessory

MS-LA1 (Sensor mounting bracket)



Set of two L-shaped brackets and four M4 (length 8 mm $0.315\ \text{in})$ screws with washers.


OPTIONS

	Designation	Model No.	Description	
Side view attachment (Note 1) LA-SV1 Versatile mounting is possible as the laser beam can be right angle. • Sensing range: 500 mm 19.685 in • Minimum sensing object: φ0.1 mm φ0.004 in • Repeatability: 20 μm 0.787 mil or less			0 mm 19.685 in object:	
	Digital panel	CA2-T2	NPN open-collector transistor	This is a very small controller which allows two independent threshold level settings. • Supply voltage: 24 V DC ± 10 % • No. of inputs: 1 No. (sensor input) • Input range: 1 to 5 V DC • Main functions: Threshold level setting function, zero-adjust function, scale setting function, hysteresis setting function, start / hold function, auto- reference function, power supply ON-delay function, etc.
	controller (Note 2)	CA-R2	Relay contact	This is a multi-functional controller having mathematical functions, hold function, etc.
		CA-T2	NPN open-collector transistor	 Supply voltage: 100 to 240 V AC ± 10 % No. of inputs: 2 Nos. (sensor input) Input range: 1 to 5 V DC Power supply for sensor: 12 V DC, 150 mA Main functions:
		CA-B2	NPN open-collector transistor With BCD output	Mathematical functions, process number selection function, hold function, scaling function, auto-reference function, power supply ON-delay function, measurement start delay function, hysteresis setting function, etc.

Notes: 1) Mount LA-SV1 on either the emitter or the receiver. If it is mounted on both sides, the monitor LEDs may not light off perfectly.

2) For further details, refer to p.864~ for the ultra-compact digital panel controller CA2 series, and to p.854~ for the digital panel controller CA series.

Side view attachment LA-SV1



Two M3 (length 10 mm 0.394 in) screws with washers are attached.

Digital panel controller





· CA series



5

 ∇

LA

٩

GP-A

LA

SPECIFICATIONS

Laser collimated beam sensors

Ser Min Rep	Conforming standard n Model No. Ising width	IEC and JIS standards	FDA standard		
Ser Ser Min Rep		L A-510	IEC and JIS standards FDA standard		
Ser Min Rep	sing width	LA-JIU	LA-511		
Min Rep		15 mm 0.591 in			
Rep	ising range	500 mm	19.685 in		
	. sensing object	φ0.1 mm φ0.004	in opaque object		
Sup	peatability	10 μm 0.39	4 mil or less		
	ply voltage	12 to 24 V DC \pm 10 %	Ripple P-P 10 % or less		
Cur	rent consumption	Emitter: 35 mA or less, Receiver: 25 mA or less			
Cor	nparative output	NPN open-collector transistor • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less (between comparative output and 0 V) • Residual voltage: 1 V or less (at 100 mA sink current) 0.4 V or less (at 16 mA sink current)			
	Utilization category	DC-12 o	or DC-13		
	Response time	0.5 ms	or less		
	Output operation	ON when the incident beam amou	unt is less than the threshold level		
	Short-circuit protection	Incorp	orated		
Ana	log output	Analog voltage • Output voltage: 1 V (Darkest) to 5 V (Lightest) • Output impedance: 75 Ω			
	Slew rate	8 V/ms	or more		
	Temperature characteristics	Within \pm 0.1 % F.S. / °C (with respect to sensing range at ambient temperature \pm 20 °C \pm 68 °F)			
Rer	note interlock input	Laser is emitted when it is connected to 0 V, but	not emitted when connected to $+$ V or kept open		
6	Operation	Red LED (lights up when the comparative output is ON)			
Indicators	Laser emission warning	Red LED (lights up when laser is being emitted)			
Indic	Stable incident beam	Green LED (lights up under the stable light received condition)			
	Laser beam alignment	Yellow LED × 4 (light up whe	en laser beam is misaligned)		
Adjusters	Threshold level	Adjustment of threshold level for the com	nparative output, 18-turn endless adjuster		
Adju	Span	Adjustment of span for the analog vol	ltage output, 18-turn endless adjuster		
	Pollution degree	3 (Industrial e	environment)		
nce	Ambient temperature	0 to + 50 °C + 32 to + 122 °F (No dew condens	ation), Storage: -20 to $+70$ °C -4 to $+158$ °F		
resistance	Ambient humidity	35 to 85 % RH, Stor	rage: 35 to 85 % RH		
_	Ambient illuminance	Sunlight: 10,000 ℓx at the light-receiving face, Inca	ndescent light: 10,000 ℓx at the light-receiving face		
Environmenta	EMC	EN 50081-2, EN 61000-6-2			
viron	Insulation resistance	20 M Ω , or more, with 250 V DC megger between all	supply terminals connected together and enclosure		
Ш	Vibration resistance	10 to 55 Hz frequency, 1.5 mm 0.059 in amplitu	ude in X, Y and Z directions for two hours each		
	Shock resistance	500 m/s ² acceleration (50 G approx.) in >	X, Y and Z directions for three times each		
Emi	tting element	Infrared semiconductor laser diode (Maximum output: 1.7 mW, Peak emission wavelength: 780 nm 0.031 mil)			
Enclosure earthing		Capacitor earth			
Material		Enclosure: Die-cast zinc alloy, Top cover: PPO, Front protection cover: Glass			
Cab	le	0.2 mm ² 5-core (emitter: 4-core) shielded cable, 3 m 9.843 ft long			
Cab	le extension (Note)	Extension up to total 50 m 164.042 ft is possible, for both emitter and receiver, with 0.3 mm ² , or more, cable. (Synchronization wire cannot be extended on the extension of t			
Weight		Emitter: 290 g approx., Receiver: 280 g approx.			
Accessories		MS-LA1 (Sensor mounting brack Adjusting screwdriver: 1 pc. Crimp contact: 2 pcs. Class 1 identification label: 1 pc. Inspection slip: 1 pc. (LA-511 onl			

Note: LA-510 and LA-511 are CE conformity product complying with EMC Directive. The harmonized standard with regard to immunity that applies to this product is EN61000-6-2 and the following conditions must be met to conform to that standard.

Conditions

This sensor should be connected less than 10 m 32.808 ft from the power supply.
The signal line to connect with this sensor should be less than 30 m 98.425 ft.
The EN 50082-2 that previously applied to the products for conforming to EMC Directive was replaced by EN 61000-6-2 starting April 1 st, 2002.

SPECIFICATIONS

LA


Laser sensor controller

Model No.		LA-C1	
Item			
Supply voltage		12 to 24 V DC ± 10 % Ripple P-P 10 % or less	
	ent consumption	260 mA or less	
POWE	er supply for sensor	12 V DC, 70 mA max.	
	Sensor input	Input voltage range: 1 to 5 V (Maximum allowable voltage: 10 V DC) Input impedance: 1 M Ω A/D conversion method: double integration method Sampling cycle: 50 ms (20 times/sec.)	
Input	Auto-reference input	Specifying timing of auto-reference function • Operation: Effective when NPN non-contact transistor input is Low • Signal condition: Low level 1.5 V or less Low level output current 0.6 mA or less Low level input time duration 0.5 ms or more	
(Comparative output	NPN open-collector transistor (3 outputs of HI, GO or LO) • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less (between comparative output and 0 V) • Residual voltage: 1 V or less (at 100 mA sink current) 0.4 V or less (at 16 mA sink current)	
		Hysteresis mode Window comparator mode	
Output	Output operation	Hysteresis HI ON output OFF GO ON output OFF LO ON output OFF LO ON OTPUT CFF CFT CF	
	Response time	100 ms or less (150 ms or less while the auto-reference input is applied)	
	Short-circuit protection	Incorporated	
r	Measurement value display	31/2 digit LCD display [Display cycle: 250 ms (4 times/sec.)]	
	Display range	- 19.99 to + 19.99	
ay	Accuracy	\pm (0.15 % $ imes$ Measurement value + 1 digit) at +23 \pm 1 °C +73.4 \pm 33.8 °F	
Display	Setting value display	3 ¹ / ₂ digit LCD display	
	Display range	- 19.99 to + 19.99	
	Comparative output operation display	LCD display of 'HI', 'GO' and 'LO' (HI, GO or LO lights up when the respective output is ON)	
	Ambient temperature	0 to + 50 °C + 32 to + 122 °F (No dew condensation), Storage: - 10 to + 60 °C + 14 to + 140 °F	
ental	Ambient humidity	35 to 85 % RH, Storage: 35 to 85 % RH	
Environmental resistance	Noise immunity	Power line: 240 Vp, 10 ms cycle, and 0.5 μ s pulse width Radiation: 300 Vp, 10 ms cycle, and 0.5 μ s pulse width (with noise simulator)	
res.	Vibration resistance	10 to 55 Hz frequency, 1 mm 0.039 in amplitude in X, Y and Z directions for two hours each	
	Shock resistance	300 m/s ² acceleration (30 G approx.) in X, Y and Z directions for three times each	
C	nection method	Screw-on terminal block	
Conn		Enclosure: Polycarbonate, Front bezel: ABS, Terminal block: PBT, Front panel: Acrylic, Protector: Acrylic	


1 A-300


LA

Laser collimated beam sensor




Emitter







Wiring diagram




Laser sensor controller I/O circuit diagram




Internal circuit -Users' circuit



Auto-reference input circuit diagram



Wiring diagram



Note: In case the receiver's comparative output wire (black) is not used, please insulate it.

۲V

SENSING CHARACTERISTICS (TYPICAL)

8

6

4

2

0+ 10 २०

0.394

Correlation between setting distance and excess gain

100 50 Output voltage (V) Excess gain 10 Ę 1 ₀ 0.5 1 1.5 2 2.5 281 4.921 6.562 8.202 3 1 Setting distance L (m ft)-

Correlation between transverse deviation and output voltage

500 mm

C

Center

Deviation ℓ (mm in)

∢ ₀

5

Left -

. 10

5

+ Right

0.

Correlation between interrupted

8

6

4

2

0

(Lightest)

10

Output voltage (V)

beam width and output voltage

10

Interrupted beam width

0.394

15


(Darkest)

5

0.197

D (mm in)

Correlation between ambient temperature and output voltage variation rate



PRECAUTIONS FOR PROPER USE

Laser collimated beam sensor



This product is not a safety sensor. Its use is not intended or designed to protect life and prevent body injury or property damage from dangerous parts of machinery. It is a normal object detection sensor.

Safety measures for laser beam products

- The safety standard IEC Publication 825 specifies the application of laser beam products. Please read it carefully before using the laser beam sensor.
- Do not expose your eyes to the laser beam through optical instruments, like a lens.

Safety standards for laser beam products


 A laser beam can harm human being's eyes, skin, etc., because of its high energy density. IEC and JIS have classified laser products according to the degree of hazard and the stipulated safety requirements.

LA-510 and LA-511 are identified as a 'Class 1' laser products.


	Class	Applicable model No.	Degree of danger	
	Class 1	LA-510 LA-511	Intrinsically safe design.	
	Class 2		Visible and low power (wavelength 400 to 700 nm 0.016 to 0.028 mil). Eyes react instinctively to laser beam and protect themselves.	
	Class 3A		Dangerous if eyes are exposed to laser beam through optical means. Visible beam should be 5 mW or less. Invisible beam should not exceed 5 times the Class 1 power.	
Class 3B — directly. Unfocused, pulsed laser radia		Dangerous if eyes are exposed to laser beam directly. Unfocused, pulsed laser radiation 0.5 W or less can be observed by means of diffuse reflection.		
	Class 4		Too intense. Even diffuse reflection is possibly dangerous. It can burn the skin or cause a fire.	

Mounting

• The emitter and the receiver must face each other with proper slit orientation so that the beam can be received.



• The tightening torque should be 1.17 N·m or less. When mounting the sensor with the attached sensor mounting bracket, the sensor must be fixed on both sides.




LA

PRECAUTIONS FOR PROPER USE

Laser collimated beam sensor


Laser collimated beam alignment

• Place the emitter and the receiver so that they face each other along a straight line and align their positions until all yellow LEDs light off and the green LED lights up.




Span adjustment

•Turn the span adjuster until the analog voltage reaches + 5 V in the perfect light received condition (perfect beam alignment). As the span adjuster is turned clockwise, the analog voltage increases.



Threshold level adjustment

• The threshold level adjuster sets the threshold level of the comparative output. As the threshold adjuster is turned clockwise, the threshold level increases.



Wiring

- · Make sure that the power supply is off while wiring.
- · Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In this sensor, capacitor earth is used to enhance the noise characteristics. In case there is a high frequency noise generating equipment, such as, an ultrasonic welding machine, etc., near the sensor head and if the mounting base is electrically conducting (metallic, etc.), then insulate the sensor head from the mounting base.

Do not use a power supply having a single-winding transformer (auto-transformer) as this can be dangerous.

- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.

Others

- The sensor's output is proportional to the amount of laser beam received. Since there is some variation in the light intensity at the center and the periphery of the sensing area, take care that 'output = dimension' may not hold.
- For stable operation, use the sensor 10 min., or more, after switching on the power supply.
- Avoid dust, dirt, and steam.
- Take care that the sensor does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.


PRECAUTIONS FOR PROPER USE

Laser sensor controller


LA


Threshold level setting

Operation panel description



Output mode






Note: In the window comparator mode, <u>SET 1</u> and <u>SET 2</u> should be separated by 2 digits or more.

Setting method

٩

agnetic Displacem

SET 1, SET 2 setting modes and Sensing mode can be cyclically selected by pressing the SET key.



• Setting procedure <Light width indication (indicated with '+')>

Step	Setting item	Display mode	Setting procedure
1	Zero-point adjustment	Sensing mode	Press the <u>0-ADJ</u> key under the Darkest condition (entire beam interrupted).
2	Full-scale adjustment	Sensing mode	Enter the sensor into the Lightest condition (entire beam is received). Turn the span adjuster until the displayed value becomes '+ 15.00'.
3	SET 1 level setting	[SET 1] setting mode	Use UP and DOWN keys to set the level of SET 1. To increase the value, press the UP key. To decrease the value, press the DOWN key. + 19.99 + 19.98 UP + 0.00 - 19.98 DOWN - 19.99
4	SET 2 level setting	SET 2 setting mode	Set the level of SET 2 with UP and DOWN keys.
5		Sensing mode	Press the SET key to complete the setting procedure.

<Interrupted beam width indication (indicated with '-')>

After completing Step 2 'Full-scale adjustment' given above, press the O-ADJ key again.

The subsequent procedure is similar to that for 'Light width indication'.

Note: The output and operation display remain unchanged while <u>SET 1</u> or <u>SET 2</u> is adjusted.

★If an error occurs, take the following corrective action.

Error code (Note 1)	Cause	Corrective action	
Err 1	Short-circuit causing excess current flow.		
ErrS	Check the set value.		
(Note 2)	 Input voltage exceeds 5.25 V. The measurement value exceeds the display range (-19.99 to + 19.99). 	The input voltage should not exceed 5.25 V. Keep the measure- ment value within the display range.	

Notes: 1) The error code blinks in the measurement value display.

2) '----' does not blink.


Ч Ч

PRECAUTIONS FOR PROPER USE

Laser sensor controller

Auto-reference function


 The auto-reference function automatically shifts the set values to compensate for any change in the reference value at the time of autoreference input.
 OFF




Application example Monitoring wire thickness

(1) Let the tolerance be ± 0.5 for a standard workpiece $(\phi 2)$. Set: <u>SET 1</u> = -0.5

SET 2 = + 0.5



② Place the standard workpiece (ϕ 2) within the sensing area and make the auto-reference input 'Low'. The set values get changed to $\underline{SET 1} = 2 + (-0.5) = 1.5$ $\underline{SET 2} = 2 + (+0.5) = 2.5$




(3) In case the standard workpiece changes to ϕ 3 and the tolerance is still \pm 0.5, place the standard workpiece (ϕ 3) within the sensing area and make the auto-reference input 'Low'. The set values get changed to SET 1 = 3 + (-0.5) = 2.5 SET 2 = 3 + (+0.5) = 3.5



• In the sensing mode, the set values obtained after the auto-reference input are displayed.

However, in the setting modes, the initial set values (in the application example, $\underline{\text{SET 1}} = -0.5$ and $\underline{\text{SET 2}} = +0.5$) are displayed.

Time chart



Note: Operation may be unstable (due to operation at the previous set values) for 150 ms immediately after the auto-reference input is applied.


Wiring

- Make sure that the power supply is off while wiring.
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- The tightening torque of screws on the terminal block should be 0.49 N⋅m or less.

Others


- Do not use during the initial transient time (1 sec.) after the power supply is switched on.
- Avoid applying an excess voltage (10 V or more) on the sensor input terminals, as it may cause malfunction.
- Avoid dust, dirt, steam, and corrosive gas.
- Take care that the controller does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.

DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/



MS-LA1

Sensor mounting bracket (Accessory for LA-510 and LA-511)




Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated) Set of two L-shaped brackets and four

M4 (length 8 mm 0.315 in) screws with washers


LA-SV1

Side view attachment (Optional)





Material: Glass (Front protection cover, Aluminum evaporated mirror) Polyetherimide (Enclosure) Two M3 (length 10 mm 0.394 in) screws with washers are attached.

Assembly dimensions




Assembly dimensions





LA

LA



DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/